


# DFWX SERIES

TECHNICAL MANUAL

ENGLISH



# Copyright

© Dini Argeo. All rights reserved.

Dini Argeo® is a registered trademark.

Dini Argeo owns the copyright for the contents of this document (including artwork, illustrations, photographs, and written material). You may not copy, reproduce, modify, republish, or distribute any material from this document without permission.

All other brand or product names within this publication are trademarks or registered trademarks of their respective companies.

Dini Argeo is a Rice Lake Weighing Systems Company.

# TABLE of CONTENTS

<b>1. INTRODUCTION AND WARNINGS</b>	<b>7</b>
<b>2. TECHNICAL SPECIFICATIONS FOR DFWX MODELS</b>	<b>8</b>
<b>3. TECHNICAL SPECIFICATIONS FOR DFWX-HGX MODELS</b>	<b>9</b>
<b>4. INDICATOR DIMENSIONS (MM)</b>	<b>10</b>
<b>5. INDICATOR COVER</b>	<b>11</b>
Remove Cover	11
Reinstall Cover	11
<b>6. INDICATOR COMPONENTS</b>	<b>12</b>
<b>7. CPU BOARD OVERVIEW</b>	<b>15</b>
<b>8. APPROVAL</b>	<b>17</b>
<b>9. SCALE CONNECTION OVERVIEW</b>	<b>18</b>
Overview Load Cell Connection Diagrams	18
Load Cell Scale Connections	19
<b>10. WIRING DIAGRAMS</b>	<b>20</b>
CPU Board (DFWX, DFWX-HGX, DFWXB, DFWXB-HGX)	20
CPU Board (DFW-ETH, DWX-ETH-HGX, DFWXB-WIFI, DFWXB-WIFI-HGX)	21
<b>11. MAXIMUM ALLOWED CABLE LENGTHS</b>	<b>22</b>
<b>12. POWER SUPPLY</b>	<b>23</b>
<b>13. EARTHING</b>	<b>24</b>
Example of Rear Earth Stud	25
Example of Grounding a Weighbridge	26
Example of Grounding a Silo	27
<b>14. OPTIONAL COMMUNICATION CABLES</b>	<b>28</b>
<b>15. CABLE GLAND TORQUE SPECIFICATIONS</b>	<b>29</b>
<b>16. VAUX POWER FOR EXTERNAL DEVICES</b>	<b>29</b>

<b>17. DIGITAL INPUTS AND OUTPUTS</b>	<b>30</b>
Digital Inputs	31
Digital Outputs	32
Alibi/Clock Jumpers	33
<b>18. DIGITAL OUTPUT SETPOINT MODE WITH HYSTERESIS</b>	<b>33</b>
<b>19. ETHERNET CONNECTION</b>	<b>34</b>
Ethernet Module Connection Configuration	34
PR80 Printer and Dini Labeler Ethernet Configuration	35
<b>20. WI-FI CONNECTION</b>	<b>36</b>
Wi-Fi Module Configuration Overview	37
Access Wi-Fi Configuration	37
Typical Wi-Fi Configuration	39
<b>21. RESET ETHERNET AND WI-FI MODULE CONFIGURATION</b>	<b>42</b>
<b>22. RF MODULE CONNECTION (Optional)</b>	<b>43</b>
Configuration	43
<b>23. BLUETOOTH CONNECTION (Optional)</b>	<b>44</b>
Configuration	44
<b>24. EXTERNAL COMMUNICATION DEVICES (Optional)</b>	<b>45</b>
Remote Control Receiver	45
Configuration	45
External Bluetooth Module	46
Configuration	46
External Radio Module	47
Configuration	47
External Module Cable	48
External Bluetooth and Radio Module Board Pinout	49

<b>25. EXTERNAL LEVEL3AX DEVICE (Optional)</b>	<b>50</b>
External Inclinometer	50
Configuration	50
External LEVEL3AX Module Cable	51
External LEVEL3AX Board Pinout	52
<b>26. Metrology Information</b>	<b>53</b>
<b>27. PROGRAMMING</b>	<b>54</b>
<b>28. PROGRAMMING MENU</b>	<b>55</b>
<i>CAL</i>	56
<i>D.CAL</i>	57
<i>CrAU</i>	58
<i>SEr iAL</i>	59
<i>LAYout</i>	81
<i>LEVEL</i>	96
<i>F iLTEr</i>	100
<i>SCrEEEn</i>	101
<i>bAtt</i>	103
<i>AutoFF</i>	103
<i>rENotE</i>	104
<i>An.out</i>	105
<i>inPutS</i>	107
<i>outPut</i>	108
<i>rESEt</i>	110
<i>d iAG</i>	110
<i>AdUIAnC</i>	112
<b>29. FIRMWARE UPDATE</b>	<b>124</b>
<b>30. SILO CALIBRATION</b>	<b>126</b>
<b>31. COMMUNICATION STRINGS</b>	<b>127</b>
Short String	127
Extended String and Extended String 2	128
Custom String	129
Available Token	130
Bits	131

<b>32. COMMUNICATION COMMANDS</b>	<b>133</b>
<b>33. PROGRAMMING ERRORS</b>	<b>135</b>
<b>34. FAQ - FREQUENTLY ASKED QUESTIONS</b>	<b>136</b>
<b>35. BATTERY REMOVAL</b>	<b>137</b>
Alibi Battery Removal/Replacement	137
Battery Removal/Replacement	140

# 1. INTRODUCTION AND WARNINGS

This product is the best solution for multi-function weighing applications, offering ease of use, high precision in reading the weight, and many functions to speed up and simplify everyday work.

This manual provides an overview of the potentials of the product. The configuration menu can be used to adapt the product functionality to the required weighing application.



## WARNINGS:

- Only use original spare parts.
- Any tampering with the equipment or use of non-original spare parts voids the warranty and relieves the manufacturer of any liability.
- Before any installation or repair that involves access to electronic parts, turn off the device and disconnect any source of power supply (battery, AC network or other).
- Always use network power supply sources regulated within  $\pm 10\%$  of the rated voltage.
- In applications in connection with third parties, always follow the specifications given on the approval decree of the equipment.
- Do not immerse in water.
- Do not use aggressive cleaning solvents or substances.
- Do not install in potentially explosive environments.
- Earth connect any earth socket located on the equipment casing, using a cable with a diameter of at least  $16 \text{ mm}^2$ .



### Product Disposal:

The crossed out wheelie bin symbol on the product shows that it must be brought to appropriate separate waste collection centres at the end of its life cycle or returned to the dealer when purchasing a new equivalent product. Proper separate collection to then send the product to recycling contributes to preventing possible negative effects on the environment and to health and promotes recycling. Users who dispose of the product illegally shall face administrative sanctions as provided for by law.

### Battery Disposal:

Dispose of batteries at appropriate waste collection centers at the end of their life cycle in accordance with local laws and regulations. Batteries and rechargeable batteries may contain harmful substances that should not be disposed of in household waste. Batteries may contain harmful substances including but not limited to: cadmium (Cd), lithium (Li), mercury (Hg) or lead (Pb). Users who dispose of batteries illegally shall face administrative sanctions as provided by law. **WARNING:** Risk of fire and explosion. Do not burn, crush, disassemble or short-circuit batteries.

**Important:** All included batteries included intended for sale in the EU are classified as "Portable Batteries for General Use" and comply with European Battery Regulation (EU) 2023/1542.

## 2. TECHNICAL SPECIFICATIONS FOR DFWX MODELS




Model	Specification		Description	
All Models	Case	Material	AISI 304 Stainless Steel	
		Protection	IP68 & IP69K	
	LCD Screen	Backlighting	RGB, 7 selectable colours	
		Brightness	5 intensity levels	
		Digit height	25 mm	
		Dimensions	136 x 40 mm	
	Keypad		5 mechanical keys + 16 membrane keys	
	Cable gland	Standard	3 x PG9	
		Extra (optional)	1 x PG7, 1 x PG9, 1 x PG13	
	Load cell inputs		1	
	Number of scales		1	
	Maximum number of connectible load cells		16 x 350 Ohm	
	Maximum input current to load cells		228 mA	
	Temperature range	Storage	-20 ÷ +60 °C	
		Internal use	-10 ÷ +40 °C	
		Type-approved	-10 ÷ +40 °C	
	Humidity		Max 85% non-condensing	
	Power supply	CPU board power range		3,3 ÷ 16 V
		Internal Power supplier		IN: 110 ÷ 240 Vac OUT: 12Vdc, 15,6 W
		Available plugs		EU, UK , US, AUS, CH (depending on model)
	Serial ports	COM1	RS232	AMP6 or terminal connections
		COM2	RS232+CTS	AMP6 connection
		COM3	RS485	Terminal connections
COM4		TTL	AMP4 connection	
COM5		TTL	For optional interfaces	
USB		USB Type-C	1 USB Type-C (internal)	
Number of divisions	Internal use		From 100 to 800,000 d Min voltage per division: 0,03 uV	
	Type approval		Single range: Up to 10,000 e Multi-range: 3000+3000+3000 e / 6000+6000 e Multi-interval: 3x3000 e / 2x6000 Min voltage per division: 0,3 uV	
Alibi Memory Standard DFWX-ETH, DFWXB-WIFI Optional DFWX, DFWXB	Number of weighings		Max 120,000	
	Date and time		Yes	
DFWX-ETH	Ethernet module	Protocols	TCP, UDP, IP, ARP, ICMP, Ethernet Mac.	
		Ethernet ports	1 LAN for configuration, 1 WAN for use	
		Speed	10-100 Mbps	
DFWXB-WIFI	Wi-Fi module	Protocols	IEEE 802.11b/g/n, WEP, WPA e WPA2-PSK(AES/TKIP)	
		Frequency	2.412 GHz - 2.462 GHz	
		Data Range	Up to 500 Kbps	
		Distance	Up to 100m indoors, up to 300m outdoor	
DFWXB, DFWXB-WIFI	Battery	Type	LiPo 3.7 V	
		Battery duration	Min (1 load cell 350 Ohm, Auto brightness, 1 Serial) - up to 80 hours Max (4 load cells 1000 Ohm, Auto brightness, Serial 1 with Wi-Fi) - up to 20 hours	




### 3. TECHNICAL SPECIFICATIONS FOR DFWX-HGX MODELS

Model	Specification		Description	
All Models	Case	Material	AISI 316 Stainless Steel	
		Protection	IP68 & IP69K	
	LCD Screen	Backlighting	RGB, 7 selectable colours	
		Brightness	5 intensity levels	
		Digit height	25 mm	
		Dimensions	136 x 40 mm	
	Keypad		5 mechanical keys + 16 membrane keys	
	Cable gland	Standard	2 x PG9 (hygienic certified)	
		Extra (optional)	1 x PG9 (hygienic certified)	
	Load cell inputs		1	
	Number of scales		1	
	Maximum number of connectible load cells		16 x 350 Ohm	
	Maximum input current to load cells		228 mA	
	Temperature range	Storage	-20 ÷ +60 °C	
		Internal use	-10 ÷ +40 °C	
		Type-approved	-10 ÷ +40 °C	
	Humidity		Max 85% non-condensing	
	Power supply	CPU board power range		3,3 ÷ 16 V
		Internal Power supplier		IN: 110 ÷ 240 Vac OUT: 12Vdc, 15,6 W
		Available plugs		EU, UK, US, AUS, CH (depending on model)
	Serial ports	COM1	RS232	AMP6 or terminal connections
		COM2	RS232+CTS	AMP6 connection
		COM3	RS485	Terminal connections
		COM4	TTL	AMP4 connection
		COM5	TTL	For optional interfaces
		USB	USB Type-C	1 USB Type-C (internal)
Number of divisions	Internal use	From 100 to 800,000 d Min voltage per division: 0,03 uV		
	Type approval	Single range: Up to 10,000 e Multi-range: 3000+3000+3000 e / 6000+6000 e Multi-interval: 3x3000 e / 2x6000 Min voltage per division: 0,3 uV		
Alibi Memory <small>Standard DFWX-ETH, DFWXB-WIFI Optional DFWX, DFWXB</small>	Number of weighings	Max 120,000		
	Date and time	Yes		
DFWX-ETH-HGX	Ethernet module	Protocols	TCP, UDP, IP, ARP, ICMP, Ethernet Mac.	
		Ethernet ports	1 LAN for configuration, 1 WAN for use	
		Speed	10-100 Mbps	
DFWXB-WIFI-HGX	Wi-Fi module	Protocols	IEEE 802.11b/g/n, WEP, WPA e WPA2-PSK(AES/TKIP)	
		Frequency	2.412 GHz - 2.462 GHz	
		Data Range	Up to 500Kbps	
		Distance	Up to 100m indoors, up to 300m outdoor	
DFWXB-HGX, DFWXB-WIFI-HGX	Battery	Type	LiPo 3.7 V	
		Battery duration	Min (1 load cell 350 Ohm, Auto brightness, 1 Serial) - up to 80 hours Max (4 load cells 1000 Ohm, Auto brightness, Serial 1 with Wi-Fi) - up to 20 hours	

## 4. INDICATOR DIMENSIONS (MM)




 Cable glands vary depending on model.




## 5. INDICATOR COVER

### Remove Cover

Use 7 mm wrench to remove M4 nuts.



7 mm




### Reinstall Cover


Position cover on protruding threaded rods and secure with nuts in a star pattern.



Torque M4 nuts to 7 N-m.




7 mm




## 6. INDICATOR COMPONENTS

DFWX-ETH, DFWX-ETH-HGX, DFWXB-WIFI, DFWXB-WIFI-HGX



ELEMENT	DESCRIPTION	DFWX-ETH	DFWXB-WIFI
A	Antenna	N/A	Standard
B	Ethernet/Wi-Fi Board with Analog Output Carrier	Standard	
C	USB Type-C Port	Standard	
D	Battery Charging Board	N/A	Standard
E	Battery	N/A	Standard
F/H	Alibi memory module can be installed in two positions, on the CPU Board (F) or on the optional Digital Input Output board (H).	Standard (F) / Optional (H)	
G	Power Supply	Standard	
I	Digital Input Output board	Optional	
J	CPU Board	Standard	
K	Analog Board	Optional	

DFWX, DFWX-HGX, DFWXB, DFWXB-HGX



ELEMENT	DESCRIPTION	DFWX	DFWXB
C	USB Type-C Port	Standard	
D	Battery Charging Board	N/A	Standard
E	Battery	N/A	Standard
F/H	Alibi memory module can be installed in two positions, on the CPU Board (F) or on the optional Digital Input Output board (H).	Standard (F) / Optional (H)	
G	Power Supply	Standard	
I	Digital Input Output board	Optional	
J	CPU Board	Standard	
K	Analog Board	Optional	
L	Carrier Board	Standard	
M	Bluetooth or RF module	Optional	

## Internal Components Overview


Brief descriptions of the hardware components displayed in this section follow.


#	Component	DESCRIPTION
A	Antenna	An Antenna with mounting hardware is included with the DFWXB-WIFI or Bluetooth/RF options.
B	Ethernet or Wi-Fi Carrier Board	DFWX-ETH and DFWX-WIFI models contain a board that provides Ethernet support or Wi-Fi (802.11b/g/n ). In addition, the Ethernet/Wi-Fi boards provide connectors and an installation location for the Analog output option. The Ethernet/Wi-Fi boards connects to the CPU Board on the J21 and J8 connectors.
C	USB Type-C Power	USB Type-C port for PC connection.
D	Battery Charging Board	The DFWXB and DFWXB-WIFI contain an additional board that facilitates charging of the included 3.7 V LiPo battery. The battery charging board has one three port connector used to the charge the include 3.7 LiPo battery. The the battery charging board connects to the CPU Board on J22.
E	LiPo Battery	The LiPo battery provides 3.7 V to operate the indicator wirelessly.
F/H	Alibi Memory Board	Provides Alibi and Clock support. The Alibi board contains a replaceable 3 V CR2032 battery. Connects either to the optional Digital Input Output board on the ALIBI connector or to the CPU board's ALIBI/CLOCK/Digital Input Output board connector.
G	Power Supply	Receives AC power from a power outlet and supplies the required 12 Vdc power to the CPU board and charge battery (if included).
I	Digital Input Output Board	Provides Digital Inputs and Outputs. A 10 pin ribbon cable connects the optional Digital Input Output board to the CPU board's ALIBI/CLOCK/DFIO connector.
J	CPU Board	Performs required weight processing, system configuration, load cell connection, and option interfacing.
K	Analog Output Board	This option provides analog outputs. The analog output option connects to the DAC connector on the Wi-Fi/Ethernet board or carrier board.
L	Carrier Board	DFWX or DFWXB contain a carrier board that provides support for the analog output option and either a Bluetooth or RF module. In addition, the carrier board provides screw terminal outputs. The carrier board connects to CPU Board on the J21 and J8 connectors.
M	Bluetooth or RF Module Board	The optional Bluetooth module supports Bluetooth version 5.0 BLE and is compatible with DFWX and DFWXB series carrier boards. The module connects to the RADIO connector on carrier board. The optional RF board provides 2.4 GHz RF. The module is compatible with DFWX and DFWXB series carrier boards. The RF module connects to the RADIO connector on carrier board.



## 7. CPU BOARD OVERVIEW

This section briefly discusses the internal components of DFWX series instruments.

The CPU board runs firmware that contains the configuration for the scale and processes the weight of measured objects. In addition, it provides the required connections for load cells, or junction boxes, keyboard and additional option boards.








ELEMENT	NAME	DESCRIPTION
A	Cell1	Scale / Load cell / Junction box connection
B	COM5	Carrier board connection
C	J21	Carrier board connection
D	USB	USB Type-C port
E	J1	<p>Sets how the CPU board is powered.</p>  <ul style="list-style-type: none"> <li>• Short the left and middle pins to power the CPU from the USB port.</li> <li>• Short the middle and right pins to power the CPU from the Vin.</li> </ul> <p><b>NOTE: J1 is set to power the CPU board with Vin by default.</b></p>
F	J22	Battery charger board connection
G	J2	Power connection
H	COM1 RS-232	COM1 RS-232 (AMP 6 pin connector)
I	COM2 RS-232	COM2 RS-232 (AMP 6 pin connector)
J	J13	Approval seal (legal for trade)
K	COM3 RS-485	COM3 RS-485 (2 screw terminal connection)

ELEMENT	NAME	DESCRIPTION
L	COM1 RS-232	COM1 RS-232 (3 screw terminal connection)
M	SW8	<p>Power configuration DIP switches (left = ON)</p>  <ul style="list-style-type: none"> <li>• 2: Automatic power on</li> <li>• 1: RS485 Termination Resistance</li> </ul>
N	N/A	485 Socket
O	BOOT	Digital input output connection or Alibi connection (for systems without Alibi connection)
P	COM4 TTL	COM4 TTL (for manufacturer use only)
Q	SENSOR	Sensor connection
R	KEYB	Keyboard connection
S	SW2	<p>Load cell configuration DIP switches (left = ON)</p>  <ul style="list-style-type: none"> <li>• Switches 1 and 2 = ON is 4-wire</li> <li>• Switches 1 and 2 = OFF is 6-wire</li> </ul>



## 8. APPROVAL




When the circuit is completed, the indicator is approved (legal for trade).


# 9. SCALE CONNECTION OVERVIEW

## Overview Load Cell Connection Diagrams

Single load cell



Junction box with four load cells



# Load Cell Scale Connections


**NOTE:**

- For 6-wire connection with "Sense", set the dip switches to OFF.
- For 4-wire connection, set the dip switches to ON.




**WARNING:** Make connections with indicator off and power supply disconnected. Comply with the electronic specifications on page 8.

## 4-wire connection




## 6-wire connection




# 10. WIRING DIAGRAMS

## CPU Board (DFWX, DFWX-HGX, DFWXB, DFWXB-HGX)



CPU Board (DFW-ETH, DWX-ETH-HGX, DFWXB-WIFI, DFWXB-WIFI-HGX)



# 11. MAXIMUM ALLOWED CABLE LENGTHS


## Load Cell, RS232 and Analog Output

Load cell	RS232	Analog output
50 metres with 6 x 0.25 mm <sup>2</sup> cable;  100 metres with 6 x 0.5 mm <sup>2</sup> cable.	15 m with baud rate up to 19200.	<b>CURRENT:</b> 100 metres with 2 x 0.25 mm <sup>2</sup> cable; 150 metres with 2 x 0.5 mm <sup>2</sup> cable; 300 metres with 2 x 1 mm <sup>2</sup> cable.  <b>VOLTAGE:</b> 50 metres with 2 x 0.25 mm <sup>2</sup> cable; 75 metres with 2 x 0.5 mm <sup>2</sup> cable; 150 metres with 2 x 1 mm <sup>2</sup> cable.

## RS485


Cable distance	Baud rate	Cable requirement
200 m	57600	Shielded twisted cable, 0.5 mm diameter
300 m	38400	Shielded twisted cable, 0.5 mm diameter
600 m	19200	Shielded twisted cable, 0.75 mm diameter
800 m	9600	Shielded twisted cable, 0.75 mm diameter
1000 m	2400 to 300	Shielded twisted cable, 0.75 mm diameter

**i** NOTE: All cables require 120 Ohm terminations on both sides.



## 12. POWER SUPPLY

The power supply is located inside the bottom of the enclosure and provides power to the CPU board. The instrument comes with power cord attached. This section illustrates various connections on the power supply.



ITEM	DESCRIPTION	COLOR
1	AC Line	Brown (EU) or Black (USA)
2	AC Neutral	Blue (EU) or White (USA)
3	Ground	Green and Yellow
4	CPU Board Ground	Black
5	CPU Board power (12 Vdc, max 150mA)	Red

## 13. EARTHING

For correct earthing and optimal system operation, the instrument, load cells, junction box, and weighing structure must be earthed.

### INSTRUMENT

The instrument must be powered by a dedicated power supply with an ground connection. Ground cables must be connected to the interior grounding stud from the power supply, power cable, and interior grounding stud on back cover. The exterior grounding stud must connect to the earth bar/post.

**NOTE:** *There are three grounding studs used with the DFWX and DFWXB models (not including Hygienex models):*

- *Enclosure interior*
- *Back panel interior*
- *Back panel exterior*

*Ground cables must be connected to the enclosure interior grounding stud from the power supply, power cable, and grounding stud on the interior back cover. The exterior grounding stud must connect to the earth bar/post (see pages 25, 26 and 27).*

### LOAD CELLS AND JUNCTION BOX

The connection must be made by connecting the earth cables to the earth bar (cables that must have a cross-section of at least 16 mm<sup>2</sup>); finally, connect the earth bar to the earth post with a cable having a cross-section of at least 50 mm<sup>2</sup>.

### EXAMPLES:

- If more load cells are connected to the instrument through a junction box, the cable shield from the transmitter and the cell cable shields must be connected to the earth socket of the junction box (refer to the junction box manual) and the junction box must be earthed using a copper cable with a cross-section of not less than 16 mm<sup>2</sup>.
- If the load cell is connected directly to the instrument (without using the junction box), the cell cable shields must be connected to the earthing point (or earth bar).
- If the weighing system involves large and/or outdoor structures (weighbridges, silos, etc.) and the distance between the junction box and the weight transmitter is greater than 10 m, connect the cell cable shields to the earth socket in the junction box.

### WEIGHING STRUCTURE

Earth the weighing structure and/or any unconnected structures (e.g. silos that release material onto the weighing structure) using cables with a cross-section of not less than 16 mm<sup>2</sup>.

Also connect the upper part with the lower part of each cell by means of a copper braid with a cross-section not less than 16 mm<sup>2</sup>.

### SERIAL CABLES AND CONNECTED INSTRUMENTS


Connect the serial cable shield to the earthing point inside the panel.




## Example of Rear Earth Stud

**i** **NOTE:** The back panel earthing stud extends from the interior to the exterior of the back panel. The external earthing stud must connect a earth cable to an earth bar (cables must have a cross-section of at least 16 mm<sup>2</sup>). The earth bar must be connected to the earth post using cable having with a cross-section of at least 50 mm<sup>2</sup>.


*This feature is not available on HYGIENX models.*



# Example of Grounding a Weighbridge




# Example of Grounding a Silo




## 14. OPTIONAL COMMUNICATION CABLES

Serial RS232\RS485 cable with USB connector for PC connection



TYPE	USB TO RS232	USB TO RS485
Part Number	RSCBPCUSB3P	RSCBPCUSB485
Pinout	(1) RX - Orange	(1) A+ - Orange
	(2) TX - Yellow	(2) B- - Yellow
	(3) GND - Black	(3) GND - Black
PC side	Type A USB	
Cable diameter	5 mm	
Cable gland	Included, PG9	
Cable length	1.5 m	

Cables for Labeller Connection




PRINTER	LP542TE	SMTPLUS	PR80
Part Number	RSCBLPA (1.5 meters) RSCBLPA10M (10 meters)		
Cable diameter	5 mm		
Cable gland	Included, PG9		
Printer side	DB9		
Pinout	(1) GND - Gray		
	(4) CTS - Brown		
	(6) TX - Pink		
Cable length	1.5 m / 10 m		

## 15. CABLE GLAND TORQUE SPECIFICATIONS

SIZE	METAL CASE	PLASTIC CASE
PG 7/M12	6.25 Nm	2.5 Nm
PG 9/M16	6.25 Nm	3.75 Nm
PG 11/NPT3/8	6.25 Nm	3.75 Nm
PG 13.5/M20/NPT1/2	6.25 Nm	3.75 Nm
PG 16	7.5 Nm	5.0 Nm
PG 21/M25/NPT3/4	10 Nm	7.5 Nm

## 16. VAUX POWER FOR EXTERNAL DEVICES

Vaux supplies power to an external device from the included battery in DFWXB or DFWX-WIFI models. A maximum of 3.7 V / 4 A power is provided by the integrated battery to a device connected to the Vaux terminal (such as a TPR printer). When power is provided to the Vaux terminal can be regulated with the DFWX firmware using the  $P_{\text{out}}/P$  parameter for  $SEr$   $RL$  configurations. This parameter allows power to transmit either when the instrument is turned on or when the instrument executes a printout. When using a printer with this parameter configured to transmit power only during printouts, ensures power is only used when necessary and conserves battery life.




## 17. DIGITAL INPUTS AND OUTPUTS

The optional Digital Input Output board supplies the DFWX with digital inputs and outputs. The card is mounted in the lower corner of the case, across from the power supply.



**NOTE:** The Digital Input Output board provides a secondary connection for ALIBI if the ALIBI/CLOCK/DFIO connector on the CPU Board is occupied.



### Specifications:


Digital outputs (DFIO, optional)	Max number	6
	Features	48 Vac / 60 Vdc 500 mA 10 Ohm max
Digital inputs (DFIO, optional)	Max number	2
	Features	12 ÷ 24 Vdc

# Digital Inputs


Specifications:

Voltage Range	12 Vdc \ 24 Vdc
---------------	-----------------

The following connection diagrams illustrate two methods for connecting digital inputs:



**INPUTS**  
12 ÷ 24 V



**INPUTS**  
12 ÷ 24 V

Configuration:


The **mPULS** menu (see page **107**) provides configuration for each input with a specific function.

# Digital Outputs


Specifications:

Voltage Range	Up to Max 48 Vdc \ 60 Vac
Max Current	Max 500 mA
Applicable Load	Max 10 $\Omega$

The following connection diagrams illustrate two methods for connecting digital outputs:



**OUTPUTS**  
48 Vac / 60 Vdc  
500 mA Max




**OUTPUTS**  
48 Vac / 60 Vdc  
500 mA Max

Configuration:


The **ouPut** menu (see page **108**) provides configuration for each output with a specific function.





## 18. DIGITAL OUTPUT SETPOINT MODE WITH HYSTERESIS

When digital outputs (see page 108) are configured as setpoints on gross or net weight, Hysteresis parameters provide activation and deactivation of independent thresholds for each digital output. Also, it avoids output connection issues due to instability and provides independent thresholds for turning on and turning off the digital outputs.




Configuration:

`h15tEr` is a submenu of `outPut` (see page 109). This provides hysteresis configuration for Output 1 through 6.

## 19. ETHERNET CONNECTION

DFWX-ETH includes an ETHERNET TCP \IP interface and a PG13 cable gland for installation of a standard Ethernet cable.



### Specifications:

Protocols	TCP, UDP, IP, ARP, ICMP, Ethernet Mac.
Ethernet ports	1 LAN for configuration 1 WAN for use
Speed	10-100 Mbps
Default IP address	192.168.16.254

### Ethernet Module Connection Configuration

The Ethernet module's IP address can be configured through the indicator's front panel.

#### Front Panel Configuration:

1. Configure IP Address in the technical menu: *SEr iAL -> Eth -> WAN IP*.

**i** NOTE: The *WAN IP* parameter provides four groups that contain up to three characters for IP address configuration. For example, *192.168.250.10*.

2. Connect an Ethernet cable to the WAN port for connection.

## PR80 Printer and Dini Labeler Ethernet Configuration


1. Open the Internet browser and navigate to the IP Address configured in the *SEr,iAL* -> *Eth* -> *HHn,iP* parameter.
  2. Enter login credentials when prompted. Username: admin, Password: admin
  3. Set the **IP Addr** parameter to connect the indicator to the printer or labeller.
- i** *NOTE: The IP Address parameter is set as the same IP Address as the printer's except for the last number*  
*For example, if the printer's IP address is 192.168.16.100 the value could be configured as 192.168.16.101.*
4. Select the **Serial 1** tab.
  5. Set the Socket Protocol Type parameter to **Tcp Client**.
  6. Set the printer's IP Address in the Remote Domain parameter.
  7. Set the printer's remote port number in the Remote Port parameter.
  8. Select **Apply**.
  9. Set *SEr,iAL* ▶ *Eth* ▶ *MODE* ▶ *HH* ▶ *DEFAULT* ▶ *TEST* (where *HH* is either *Pr80* or *LABEL*) and test the printout.

The screenshot shows the Hi-Link configuration interface for Serial 1. The 'Serial 1' tab is selected and highlighted with a red box. The configuration table below shows various parameters with their current values and updated values. A red box highlights the 'Socket Protocol Type', 'Remote Domain', and 'Remote Port' settings. The 'Apply' button is also highlighted with a red box.

	Current	Updated
Baudrate	115200	<input type="text" value="115200"/>
Data Width	8	<input type="text" value="8"/>
Parity	NONE	<input type="text" value="NONE"/>
Stop Bit	1	<input type="text" value="1"/>
Flow Control	Disable	<input type="text" value="Disable"/>
Socket Protocol Type	Tcp Server	<input type="text" value="Tcp Client"/>
Remote Domain	192.168.16.100	<input type="text" value="192.168.16.223"/>
Remote Port	0	<input type="text" value="9100"/>
Locale Port	8081	<input type="text" value="8081"/>
Packet Framing Lenth	200	<input type="text" value="200"/>
Packet Framing Timeout	20	<input type="text" value="20"/>
Packet Framing Interval	2	<input type="text" value="2"/>
TCP Connect Timeout	200	<input type="text" value="200"/>
Reconnect Interval	200	<input type="text" value="200"/>
TCP Keep Alive	1	<input type="text" value="1"/>
Login Enable	Disable	<input type="text" value="Disable"/>

## 20. WI-FI CONNECTION

DFWXB-WIFI includes a Wi-Fi card that connects to a wireless network through a variety of protocols.



### Specifications:


Protocols	IEEE 802.11b/g/n, WEP, WPA e WPA2-PSK(AES/TKIP)
Ethernet ports	1 LAN for configuration 1 WAN for use
Speed	10-100 Mbps
Default IP address	192.168.16.254


## Wi-Fi Module Configuration Overview

The Wi-Fi configuration is comprised of two sections:

- Access Wi-Fi Configuration
- Setting up Wi-Fi Configuring

### Access Wi-Fi Configuration

1. Power on the indicator.
  2. Open the PC's Wi-Fi connection settings and Locate the Wi-Fi module's SSID broadcast. The Wi-Fi broadcast is in the format of: "Hi-Link\_XXXX", where XXXX is the last four characters of the LAN Wi-Fi MAC address.
-  **NOTE:** To view the MAC address perform the *MAC .Add* function on page 111.
3. Connect to the Wi-Fi broadcast. The default password is "12345678".



4. Open an internet browser and then navigate to the IP address of the module:


**http://192.168.16.254/**

**i** **NOTE:** This is the default IP address and varies if the configuration is changed.

5. Enter user credentials to sign in to the configuration.


**i** **NOTE:** The default credentials are: Username = admin and Password = admin

6. Select **Sign in**.



The image shows a 'Sign in' dialog box. At the top, it says 'Sign in' followed by the URL 'http://192.168.16.254' and a warning 'Your connection to this site is not private'. Below this are two input fields: 'Username' with the text 'admin' and 'Password' with six dots. At the bottom, there are two buttons: a blue 'Sign in' button and a white 'Cancel' button with a blue border.

7. The configuration page displays.



The image shows the HI-Link configuration page. The top header is blue with the 'HI-Link' logo. Below the header, there are tabs for 'Settings', 'Network', 'Serial 0', and 'Serial 1'. The 'Network' tab is selected. The main content area is a table with two columns: 'Current' and 'Updated'. The table lists various network settings with their current values and updated values, some of which are in dropdown menus or input fields. At the bottom, there are two buttons: 'Apply' and 'Cancel'.


	Current	Updated
Network Mode	Default	Default ▾
IP Type	DHCP	DHCP ▾
AP Enable	Enable	Enable ▾
AP SSID	HI-LINK_FBC3	HI-LINK_FBC3
AP EncType	WPA2AES	WPA2AES ▾
AP Passwd	12345678	12345678
LAN IP Addr	192.168.16.254	192.168.16.254
LAN Mask	255.255.255.0	255.255.255.0
DHCP Server	Enable	Enable ▾

## Typical Wi-Fi Configuration

Typically the Wi-Fi module is set with a static (user defined) IP Address. This ensures the IP address of the module does not change.

**i** **NOTE:** A static IP address is not used by the DHCP service.


1. Select the Network Mode drop-down menu.



The screenshot shows the 'Settings' page with the 'Network' tab selected. The 'Current' and 'Updated' columns are visible. The 'Network Mode' dropdown menu is open, showing options: Default, ETH, WIFI(STA), WIFI(AP), AP Client, and Bridge. The 'Current' value is 'Default' and the 'Updated' value is 'Default'.

	Current	Updated
Network Mode	Default	Default
IP Type	DHCP	
AP Enable	Enable	
AP SSID	HI-LINK_FBC3	
AP EncType	WPA2AES	

2. Select **WIFI(STA)**.



The screenshot shows the 'Settings' page with the 'Network' tab selected. The 'Current' and 'Updated' columns are visible. The 'Network Mode' dropdown menu is set to 'WIFI(STA)'. The 'Current' value is 'Default' and the 'Updated' value is 'WIFI(STA)'. The 'STA SSID' field is empty, and the 'Scan' button is visible. The 'STA EncType' dropdown menu is set to 'Open'. The 'STA Passwd' field is empty. The 'IP Type' dropdown menu is set to 'DHCP'. The 'Apply' and 'Cancel' buttons are visible at the bottom.

	Current	Updated
Network Mode	Default	WIFI(STA)
STA SSID		
STA EncType	Open	Open
STA Passwd		
IP Type	DHCP	DHCP


3. Set the SSID:
  - a. Enter the SSID in the STA SSID Field.
  - b. If unknown, select **Scan** near the **STA SSID** field.

Network Mode	Default	WIFI(STA) ▼
STA SSID		Scan

The system populates a list of SSIDs in proximity to the PC. Copy the name of the desired SSID. Return to the Wi-Fi configuration page. Paste the SSID name into the **STA SSID** field.

Scan AP List							
Ch	SSID	BSSID	Security	Signal(%)	W-Moe	ExtCh	NT
3	DLAN	77.5a.1c.3d.ac.d7	WPA2PSK/TKIPAES	78	11b/g/n	NONE	In
3	lan	77.5a.1c.3d.a9.d7	NONE	13	11b/g/n	NONE	In
3	Guest2	77.5a.1c.3d.ac.d7	WPA2PSK/TKIPAES	78	11b/g/n	NONE	In
3	DLA2	77.5a.1c.3d.a9.d7	WPA2PSK/TKIPAES	13	11b/g/n	NONE	In
3	lan	77.5a.1c.3d.ac.d7	NONE	78	11b/g/n	NONE	In
3	Guest2	77.5a.1c.3d.a9.d7	WPA2PSK/TKIPAES	10	11b/g/n	NONE	In
6	WIFI2	77.b5.c2.42.74.d7	WPA1PSKWPA2PSK/TKIPAES	100	11b/g/n	BELOW	In

4. If needed enable security encryption:
  - Set the Wi-Fi encryption in the **STA EncType** drop-down menu.
  - If needed, enter the Wi-Fi password into the **STA Password** field.

 **NOTE** : The default encryption is set as Open. It is recommended to configure a security encryption.

Network Mode	Default	WIFI(STA) ▼
STA SSID	WIFI2345	Scan
STA EncType	Open	WPAAES ▼
STA Passwd	*****	

5. Set the following Static IP settings:
  - IP address
  - Subnet Mask
  - Default Gateway
  - Primary DNS Server (optional)


IP Type	DHCP	Static ▼
IP Addr	0.0.0.0	0.0.0.0
Mask	0.0.0.0	0.0.0.0
Gateway	0.0.0.0	0.0.0.0
Dns	0.0.0.0	0.0.0.0




6. When configuration is complete, select **Apply**.



7. The settings are applied and a countdown timer is displayed before the Wi-Fi module automatically reboots.

 **NOTE:** Don't forget if you changed IP addresses to enter the new one when revisiting.



## 21. RESET ETHERNET AND WI-FI MODULE CONFIGURATION

There are two methods for resetting the Ethernet/Wi-Fi configuration:


Via the reset Parameter in Technical menu:

1. Access the Ethernet reset parameter (see page **76**).
2. Perform the Reset function.

Via the ESO button:

1. Press and hold the ESO button for 10 seconds.
2. The Ethernet Port LEDs blink twice indicating the module is reset.


**i** **NOTE:** Only use the ESO button if the reset parameter in the Technical menu does not reset the configuration.



## 22. RF MODULE CONNECTION (OPTIONAL)

When the RF2G4X-x Radio module is installed, it sends and receives information over low power radio communication. The radio module works in a transparent mode, sending and receiving any standard string without the need for extra characters. When RF2G4X-x module is installed, a specific antenna is installed on top of the case. This antenna does not impact the IP rating of the indicator.

**i** NOTE: The RF module is only available with the DFX and DFWXB models.



### Specifications

Frequency	From 2.4 Ghz
Max power	6 dbm
Number of selectable channels	Up to 38
Communication distance	Up to 60 m indoors, up to 80 m outdoors
RED certification	Yes
Antenna	Yes

### Configuration


Configure the radio module with the `rFd id` parameter (see page 71). This parameter provides radio channel, communication mode and communication string selection.

**i** NOTE: `rFd id` only appears if a radio module is installed and correctly communicates with the indicator CPU

## 23. BLUETOOTH CONNECTION (OPTIONAL)

When the BLTX-x module is installed, it sends and receives information over low power Bluetooth communication (BLE). The Bluetooth module sends and receives any standard string without the need for extra characters. When the BLTX-x module is installed, a specific antenna is installed on top of the case that does not impact the IP rating of the indicator.

**i** NOTE: The Bluetooth module is only available with the DFX and DFWXB model



Specifications:

Frequency	2.4 Ghz
Name	BLEDA_nnnnnnnn (where nnnnnnnn is the serial number)
Version	5.0 (BLE)
Communication distance	Up to 30 m indoors, up to 100 m outdoors
RED certification	Yes
Antenna	Yes

### Configuration

Set up the bluetooth module with `bLE` menu (see page 77). This menu allows initializing the Bluetooth module, selecting the communication mode and communication string.


**i** NOTE: `bLE` only appears if the Bluetooth module is present and correctly communicates with the indicator CPU.

## 24. EXTERNAL COMMUNICATION DEVICES (OPTIONAL)

### Remote Control Receiver

An remote control is available for the DFWX. The remote control kit is supplied with a 433 Mhz receiver that is contained within an external enclosure. The receiver connects to a communication port in the DFWX (typically COM2).

**i** NOTE: The cable is attached to the receiver box from the factory through a included metal cable gland.



### Configuration

Configure the `remote` parameter (see page 104) to enable the type of remote and communication port.


**i** For remote control pairing information, see the DFWX Series User manual.

## External Bluetooth Module

An external Bluetooth module is available for the DFWX. Typically this module is used by customers with DFWX-ETH / DFWXB-WIFI models that also require Bluetooth. This module connects to Com1 or Com2 on the CPU board.

**i** NOTE: The cable is attached to the Bluetooth module from the factory.

**i** NOTE: The cable is attached to the receiver box from the factory (typically to COM2 in the DFWX).



Specifications:

Frequency	2.4 Ghz
Name	BLEDA_nnnnnnnn (where nnnnnnnn is the serial number)
Version	5.0 (BLE)
Communication distance	Up to 30 m indoors, up to 100 m outdoor
RED certification	Yes
Antenna	Yes

## Configuration


Configure the module with the `oBLE` parameter (see page 79). This parameter provides communication port selection and module initialization.

## External Radio Module

An external radio module is available for the DFWX. Typically this module is used by customers with DFWX-ETH / DFWXB-WIFI models that also require radio. This module connects to Com1 or Com2 on the CPU board.



**NOTE:** The cable is attached to the receiver box from the factory (typically to COM2 in the DFWX).



Specifications:

Frequency	2.4 Ghz
Communication distance	Up to 60m indoors, up to 80 m outdoors
Antenna	Yes
Number of selectable channels	Up to 38
RED certification	Yes


## Configuration

Configure the module with the `oBrF` parameter (see page 79). This parameter provides communication port selection and channel number.

## External Module Cable

This cable connects the Bluetooth or Radio module board in external box to the CPU board.

**i** **NOTE:** The cable is attached to the receiver box from the factory (typically to COM2 in the DFWX).




**i** **NOTE:** The external Bluetooth and Radio boards contain the same terminal block connection.

DESCRIPTION	
Part Number	14CAVOOBRFX
CPU board side	6 pin connector
Pinout	(1) GND - Brown
	(3) +5 V - Green
	(5) TX - Yellow
	(6) RX - White
Cable length	300 mm




## External Bluetooth and Radio Module Board Pinout

The external Bluetooth and Radio connect to the CPU board via typically COM2 and supplied cable. To access the Bluetooth or Radio board remove the 4 bolts and cover.



**NOTE:** The external Bluetooth and Radio boards contain the same terminal block connections.




## 25. EXTERNAL LEVL3AX DEVICE (OPTIONAL)

### External Inclinometer

An inclinometer is available for the DFWX and installed in an external enclosure. The inclinometer connects to a communication port in the DFWX (typically COM2) and reads the inclination of the weighing surface and compensates the weight, increasing precision with inclination conditions.

 **NOTE:** The cable is attached to the inclinometer enclosure from the factory through a included metal cable gland.



Specifications:

Communication	RS232/RS485 communication port on terminal block
Operating temperature	-10/+40°C
Power	3.7 V to 5 V

### Configuration


Configure the `LEUEL` parameter (see page 96) to set the communication port and calibration.

## External LEVEL3AX Module Cable

This cable connects the inclinometer module board in external box to the CPU board.



**NOTE:** The cable is attached to the receiver box from the factory (typically to COM2 in the DFWX).





DESCRIPTION	
CPU board side	6 pin connector
Pinout	(1) RX - Yellow
	(2) TX - Green
	(4) +5 V - Brown
	(6) GND - White
Cable length	3 m

## External LEVEL3AX Board Pinout

The external LEVEL3AX connects to the CPU board typically on COM2.


To access the LEVEL3AX board remove the 4 bolts and top cover, and then 3 screws and PCB cover.




# 26. METROLOGY INFORMATION

How to access metrology information

## 1. Turn off the scale



## 2. Follow the procedure:




Menu Item	Description
HH.YY	xx = Prefix: instrument model yy = Version: legal software
AA.BB.CC	Weighing program version
dFBH	Product name
-I- 1.00	Hardware identification (for manufacturer purposes)
HHHHH.H	Calibration parameters: Capacity and resolution
h irES or LEGAL	Hires = internal use configuration Legal = legal for trade configuration
9. HHHHHH	Gravity acceleration value in use


# 27. PROGRAMMING


How to access the programming menu

## 1. Turn off the scale




## 2. Follow the procedure:








 How to save and exit the menu

To save the programming changes made, press button  repeatedly while navigating the menu backwards, until the message **SAVEP** appears: press  to save or  to exit without saving.

Example (read from right to left):



## 28. PROGRAMMING MENU

	CAL	Calibration	56
	▼		
	DCAL	Zeroing the pre-tare (zero calibration)	57
	▼		
	GrAV	Area of gravity of the place of use	58
	▼		
	SERIAL	Serial ports configuration	59
	▼		
	LAYout	Print customisation	81
	▼		
	LEVEL	Inclinometer configuration	96
	▼		
	FILTEr	Weighing filter	100
	▼		
	SCrEEen	Adjusting the display	101
	▼		
	bAtt	Battery use	103
	▼		
	AutoFF	Auto switch-off	103
	▼		
	rEMote	Using the remote control	104
	▼		
	An.out	Analogue output	105
	▼		
	inPutS	Digital inputs	107
	▼		
	outPut	Digital outputs	108
	▼		
	rESEt	Factory configuration reset	110
	▼		
	dIAG	Diagnostics	110
	▼		
	AdVAnC	Advanced	112
	▼		

# MENU


How to enter	How to browse	How to save and exit
1. Off	↑ =	 
2. On	↓ =	
3.	→ =	
Page 54	← =  /	

- A CAL
- B 0.CAL
- C GrAU
- D SEr AL
- E LAYout
- F LEUEL
- G F ILtEr
- H SCrEEEn
- I bAtE
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdUAnC

## CAL A. Quick Calibration (1000+F)

NOTE: For advanced calibration\Multirange\Multidivision see pages 112, 115 and 116. For silo calibraton, see page 126.

Start of the calibration procedure:







# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B **D.CAL**

C GrAU

D SEr iAL

E LAYout

F LEVEL

G F iLteR

H SCrEEEn

I bAtte

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG



Q AdUAnC

## D.CAL B. Zeroing the Dead Load (1003+F)














This procedure zeroes the dead load and changes all calibration point proportionally while keeping the same calibration curve.

Acquisition of the zero point




D.CAL





How to enter	How to browse	How to save and exit
1. Off 	↑ = 	
2. On 	↓ = 	
3. 	→ = 	
 Page 54	← =  / 	

- A CAL
- B D.CAL
- C GrAU**
- D SEr iAL
- E LAYout
- F LEUEL
- G F ILtEr
- H SCrEEEn
- I bAtt
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdUAnC

**GrAU** C. Area of gravity of the place of use 

This parameter allows you to correct the gravity acceleration value. Before calibration, set the acceleration due to gravity (g m/s<sup>2</sup>). Calibrate the scale. Set this value to the value of the zone of use. Any difference between the two values will be automatically compensated.





 **NOTE:** In the case of an approved transmitter, the value is read-only.

**C** GrAU  9.80543 



SEr iAL ←

Area of gravity  
(9.7500 1...9.84999)

How to set the value


   

or

 ... 

**EXAMPLE:**

1. Before calibration, in the GrAU parameter enter the value 9.80543.
2. Calibrate the indicator.
3. Before using the indicator, in the GrAU parameter enter the value 9.77623.



How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 54	← =	


Navigation menu showing options A through Q. Option D 'SERIAL' is highlighted, leading to 'CoN1'. From 'CoN1', option 1 'Node' is highlighted, leading to 'Protocol'.

**SERIAL D. Configuration of the serial ports ()**











**CoN1 Communication with PC, PLC or Repeater**

Name	Type	Connection
COM1	RS232	Screw Terminal OR AMP6 (6 Pin)

Communication mode selection



**i** NOTE: Only one printer (tPr, Pr80, LABEL) can be set for all ports (CoN1, CoN2, CoN3, etc). If a printer is configured on a port, previously configured ports are switched to ondE.

How to enter	How to browse	How to save and exit
1. Off 	↑ = 	
2. On 	↓ = 	
3. 	→ = 	
 Page 54	← =  / 	

A	CAL
B	DCAL
C	GrAU
D	SEr iAL
E	LAYout
F	LEVEL
G	F ILtEr
H	SCrEEEn
I	bAtt
J	AutoFF
K	rENotE
L	An.out
M	inPutS
N	outPut
O	rESEt
P	d iAG
Q	AdUAnC


1	CoN1
2	CoN2
3	CoN3
4	CoN4
5	uSb
6	Eth
7	bLE
8	AdUAnC


  

1	Node
2	ProtoC
3	bAud
4	b it
5	CtS
6	POdER.P


Selection of the data string:

 Visible only if Node (D-1-1) = Cont in, StAbLE, onDE, 485 or Pr int .f.



 NOTE: See page 127 for string descriptions.

Communication speed (Baud rate)





# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54


How to browse

- =
- =
- =
- =


How to save and exit



Page 54




## Configuration of the serial bits



## Computer to Screen (CTS) Printer control signal

Visible only if Node (D-2-1) = tPr, Pr80, or LABEL.



ENuL = Is a free adjustment of the number of characters to send (nChar) but the duration in seconds is set in the t.nE parameter.

CTS parameter details:

- no = No signal (PC)
- LoB = Active low: LP542TE, TPR, PR80
- hiGh = Active high
- ENuL = Emulation of the signal



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54


How to browse

- =
- =
- =
- = /


How to save and exit



Page 54












## Printer power supply / Radio-frequency module



**NOTE:** The configuration of this parameter is repeated in each of the instances of the remaining communication protocols: CoN1, CoN2 (see page 63), CoN3 (see page 66), and CoN4.

**NOTE:** The CPU board VAUX (power auxiliary output) connector provides power from a DFWX's internal battery to an external device (for example a printer). For more information, see page 20. Batteries are supplied with select DFWX models.

How to enter	How to browse	How to save and exit
1. Off 	↑ = 	
2. On 	↓ = 	
3. 	→ = 	
 Page 54	← = 	

Navigation path: **SErIAL** → **CoN2** → **Node**


A	CAL
B	OCAL
C	GrAU
D	SErIAL
E	LAYout
F	LEVEL
G	FILtEr
H	SCrEEEn
I	bAtt
J	AutoFF
K	rENotE
L	An.out
M	inPutS
N	outPut
O	rESEt
P	dIAG
Q	AdVAnC


1	CoN1
2	CoN2
3	CoN3
4	CoN4
5	uSb
6	rAd io
7	Eth
8	bLE
9	AdVAnC















1	Node
2	Protoc
3	bAud
4	b it
5	CtS
6	PodEr.P

Name	Type	Connection
COM2	RS232 with CTS	AMP6 (6 Pin)

### Selection of the communication mode



 Only one printer (tPr, Pr80, LABEL) can be set for all ports (CoN1, CoN2, CoN3, etc). If a printer is configured on a port, previously configured ports are switched to onDE.

How to enter	How to browse	How to save and exit
1. Off 	 = 	
2. On 	 = 	
3. 	 = 	
 Page 54	 =  / 	

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEEn

I bAtt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 uSb

6 Eth

7 bLE

8 AdUAnC

1 Node

2 ProtoC


3 bAud


4 b it

5 CtS

6 PoDEr.P


Selection of the protocol:

 Visible only if Node (D-2-1) = Cont in, StABLE, 485, onDE, or Pr int . f.




 NOTE: See page 127 for string descriptions.

Communication speed (Baud rate)



Configuration of the serial bits





How to enter	How to browse	How to save and exit
1. Off	↑ =	 
2. On	↓ =	
3.	→ =	
Page 54	← =	

A	CAL
B	OCAL
C	GrAU
D	SEr AL
E	LAYout
F	LEVEL
G	F ILtEr
H	SCrEEEn
I	bAtt
J	AutOFF
K	rENotE
L	An.out
M	inPutS
N	outPut
O	rESEt
P	d iAG
Q	AdUAnC


1	CoN1
2	CoN2
3	CoN3
4	CoN4
5	uSb
6	rAd io
7	Eth
8	bLE
9	AdUAnC

1	Node
2	ProtoC
3	bAud
4	b it
5	CtS
6	POHEr.P

Computer to Screen (CtS) Printer control signal

Visible only if Node (D-2-1) = tPr, Pr80, or LABEL.




ENuL = Is a free adjustment of the number of characters to send (nChAr) but the duration in seconds is set in the t iNE parameter.

CtS parameter details:

- no = No signal (PC)
- LoB = Active low: LP542TE, TPR, PR80
- h iGh = Active high
- ENuL = Emulation of the signal




Printer power supply / Radio-frequency module








NOTE: The configuration of this parameter is repeated in each of the instances of the remaining communication protocols: CoN1, CoN2 (see page 63), CoN3 (see page 66), and CoN4.

NOTE: The CPU board VAUX (power auxiliary output) connector provides power from a DFWX's internal battery to an external device (for example a printer). For more information, see page 20. Batteries are supplied with select DFWX models.


*How to enter*



- Off 
- On 
- 

*How to browse*

- ↑ = 
- ↓ = 
- =  OK
- ← =  C / 

*How to save and exit*



 Page 54  Page 54

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEUEL

G F ILtEr

H SCrEEEn

I bAtt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 uSb

6 Eth

7 bLE

8 AdUAnC

1 Node

2 ProtoC

3 bAud


4 b it


5 CtS

6 PoDEr.P

Name	Type	Connection
COM3	RS485	Screw Terminal

Selection of the communication mode



 Only one printer (tPr, Pr80, LABEL) can be set for all ports (CoN1, CoN2, CoN3, etc). If a printer is configured on a port, previously configured ports are switched to onDE.

How to enter	How to browse	How to save and exit
1. Off	=	
2. On	=	Page 54
3.	=	
Page 54	=	

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEen

I bAtt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 uSb

6 rAd io

7 Eth

8 bLE

9 AdUAnC

1 NoDE

2 ProtoC

3 bAud


4 b it

5 CtS

6 PoDEr.P


Selection of the protocol:

Visible only if NoDE (D-3-1) = Cont in, Pr int .f, or Pr int .f.




NOTE: See page 127 for string descriptions.

Communication speed (Baud rate)



Configuration of the serial bits





# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit



Page 54

A **CAL**

B **OCAL**

C **GrAU**

D **SEr AL**

E **LAYout**

F **LEVEL**

G **FILtEr**

H **SCrEEr**

I **bAtt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CoN1**

2 **CoN2**

3 **CoN3**

4 **CoN4**

1 **Node**

2 **ProtoC**


3 **bAud**

4 **b it**

5 **CtS**

6 **PodEr.P**

9 **AdUAnC**




**ENuL** = Is a free adjustment of the number of characters to send (**nChar**) but the duration in seconds is set in the **t iNE** parameter.

**CtS** parameter details:

- **no** = No signal (PC)
- **ENuL** = Emulation of the signal

## Printer power supply / Radio-frequency module



**NOTE:** The configuration of this parameter is repeated in each of the instances of the remaining communication protocols: **CoN1**, **CoN2** (see page 63), **CoN3** (see page 66), and **CoN4**.

**NOTE:** The CPU board VAUX (power auxiliary output) connector provides power from a DFWX's internal battery to an external device (for example a printer). For more information, see page 20. Batteries are supplied with select DFWX models.

## CoN4 COM4 TTL

**D-4** For manufacturer use only.



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEr

I bAtE

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 USB

6 rAd io

7 Eth

8 bLE

9 AdUAnC

1 Node

2 ProtoC


3 CtS

## USB

## USB Port

Name	Type	Connection
USB	USB Port	USB Type-C

### Communication mode selection



*Only one printer (tPr, Pr80, LABEL) can be set for all ports (CoN 1, CoN2, CoN3, etc). If a printer is configured on a port, previously configured ports are switched to ondE.*

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 54	← =  /	

A	CAL
B	OCAL
C	GrAU
D	SEr AL
E	LAYout
F	LEVEL
G	F ILtEr
H	SCrEEEn
I	bAtt
J	AutoFF
K	rENotE
L	An.out
M	inPutS
N	outPut
O	rESEt
P	d iAG
Q	AdUAnC


1	CoN1
2	CoN2
3	CoN3
4	CoN4
5	uSb
7	rAd io
7	Eth
8	bLE
9	AdUAnC


1	Node
2	ProtoC
3	CtS

## Selection of the protocol:

Visible only if Node (D-5-1) = Cont in, Stable, or Print.F.



NOTE: See page 127 for string descriptions.



*Emul* = Is a free adjustment of the number of characters to send (*nChar*) but the duration in seconds is set in the *tIME* parameter.

*CtS* parameter details:

- *no* = No signal (PC)
- *Emul* = Emulation of the signal



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEEn

I bAtE

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 uSb

6 rAd iO

7 Eth

8 bLE

9 AdUAnC

1 ChAn

2 Node

3 ProtoC

4 CtS


## rAd iO Radio Configuration

Port connection of radio-frequency module

**D-6**

Visible only if a radio module is installed.


Channel Configuration



How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 54	← =  /	

A	CAL	
B	OCAL	
C	GrAU	
D	SEr AL	
E	LAYout	1 CoN1
F	LEVEL	2 CoN2
G	F ILtEr	3 CoN3
H	SCrEEen	4 CoN4
I	bAtE	5 uSb
J	AutOFF	6 rAd io
K	rENotE	7 Eth
L	An.out	8 bLE
M	inPutS	9 AdUAnC
N	outPut	4 CtS
O	rESEt	
P	d iAG	
Q	AdUAnC	

## Communication mode selection



Only one printer (tPr, Pr80, LAbEL) can be set for all ports (CoN1, CoN2, CoN3, etc). If a printer is configured on a port, previously configured ports are switched to ondE.



# MENU

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 54	← =	


A	CAL
B	OCAL
C	GrAU
D	SEr AL
E	LAYout
F	LEVEL
G	F ILtEr
H	SCrEEEn
I	bAtE
J	AutOFF
K	rENotE
L	An.out
M	inPutS
N	outPut
O	rESEt
P	d iAG
Q	AdUAnC

1	CoN1
2	CoN2
3	CoN3
4	CoN4
5	uSb
6	rAd io
1	ChAn
2	nOde
3	ProtoC
4	CtS

## Selection of the protocol:


Visible only if *nOde* (D-5-12) = *Cont in*, *StAbLE*, or *Pr int.f.*



NOTE: See page 127 for string descriptions.

## Computer to Screen (CtS) Printer control signal

Visible only if *nOde* (D-6-2) = *tPr*, *PrBO*, or *LABEL*.



*EMUL* = Is a free adjustment of the number of characters to send (*nChar*) but the duration in seconds is set in the *tIME* parameter.

*CtS* parameter details:

- *no* = No signal (PC)
- *EMUL* = Emulation of the signal



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54


How to browse

- =
- =
- =
- = /

How to save and exit



Page 54



## Eth


### Ethernet Port

Name	Type	Connection
Ethernet port	Ethernet Device	RJ45 (WAN)
















Visible only if Ethernet or Wi-Fi module is installed.

#### Communication mode selection





Only one printer (tPr, Pr80, LABEL) can be set for all ports (CON 1, CON2, CON3, etc). If a printer is configured on a port, previously configured ports are switched to onDE.


How to enter	How to browse	How to save and exit
1. Off 	 = 	
2. On 	 = 	
3. 	 = 	
 Page 54	 = 	


A	CAL	
B	OCAL	
C	GrAU	
D	SEr AL	
E	LAYout	1 CoN1
F	LEVEL	2 CoN2
G	F ILtEr	3 CoN3
H	SCrEEen	4 CoN4
I	bAtt	5 uSb
J	AutoFF	6 rAd io
K	rENotE	7 Eth
L	An.out	8 bLE
M	inPutS	9 AdUAnC
N	outPut	3 CtS
O	rESEt	4 rESEt
P	d iAG	5 bAn iP
Q	AdUAnC	


Selection of the protocol:

 Visible only if Node (D-7-1) = Cont in, StAbLE, or Pr int .f.













 NOTE: See page 127 for string descriptions.



 *Emul* = Is a free adjustment of the number of characters to send (*nChar*) but the duration in seconds is set in the *t iNE* parameter.

*CtS* parameter details:

- *no* = No signal (PC)
- *Emul* = Emulation of the signal

How to enter	How to browse	How to save and exit
1. Off 	↑ = 	
2. On 	↓ = 	
3. 	→ = 	
 Page 54	← =  / 	

A CAL

B O.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEEn

I bAtE

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 uSb

6 rAd io

7 Eth

8 bLE

9 AdUAnC

1 Node

2 ProtoC

3 CtS

4 rESEt

5 WAn IP


1 in it


2 Node

3 ProtoC


4 CtS

Resets the Ethernet/Wi-Fi module to default settings where the access point SSID is HI-LINK\_XXXX and the LAN port IP address is 192.168.16.254.


 **NOTE:** For information about configuring the Ethernet/Wi-Fi module, see 34 and 36.



Sets WAN IP address in 4 sections of up to 3 numbers.




**bLE** Bluetooth Module

 Visible only if Bluetooth module is installed.

Initializes the Bluetooth module with the device name BLEDA-XXXXX, where XXXXX is the serial number of the indicator.

Configuration of the serial protocol



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =


How to save and exit



Page 54

A	CAL		
B	OCAL		
C	GrAU		
D	SEr AL		
E	LAYout	1	CoN1
F	LEVEL	2	CoN2
G	F ILtEr	3	CoN3
H	SCrEEen	4	CoN4
I	bAtt	5	uSb
J	AutoFF	6	rAd io
K	rENotE	7	Eth
L	An.out	8	bLE
M	inPutS	9	AdUAnC
N	outPut	1	in it
O	rESEt	2	Node
P	d iAG	3	ProtoC
Q	AdUAnC	4	CtS

## Communication mode selection



Only one printer (tPr, Pr80, LAbEL) can be set for all ports (CoN1, CoN2, CoN3, etc). If a printer is configured on a port, previously configured ports are switched to andE.



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54


How to browse

- =
- =
- =
- = /

How to save and exit




Page 54




Selection of the protocol:

Visible only if Node (D-8-2) = Cont in, StAbLE, or Pr int .f.



NOTE: See page 127 for string descriptions.



EMUL = Is a free adjustment of the number of characters to send (nChar) but the duration in seconds is set in the tIME parameter.

CTS parameter details:


- no = No signal (PC)
- EMUL = Emulation of the signal

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 54	← =	

Navigation menu structure:


- A [CAL]
- B [O.CAL]
- C [GrAU]
- D [SEr AL] →
- E [LAYout] 1 [CoN1]
- F [LEVEL] 2 [CoN2]
- G [F ILtEr] 3 [CoN3]
- H [SCrEEen] 4 [CoN4]
- I [bAtt] 5 [uSb]
- J [AutOFF] 6 [rAd io]
- K [rENotE] 7 [Eth]
- L [An.out] 8 [bLE]
- M [inPutS] 9 [AdUAnC] →
- N [outPut] 1 [obrF]
- O [rESEt] 2 [obbLE]
- P [d iAG]
- Q [AdUAnC] 3 [tErN]
- 4 [iGnorE]
- 5 [2Er.5tr]

Management of the external radio frequency module (OBRF2G4X).



**i** NOTE: For more information about the external module see, page 47.

Management of the external Bluetooth module (OBBLTHX).



**i** NOTE: For more information about the external module see, page 46.

(\*) Initializes the Bluetooth module with the device name BLEDA-XXXXX, where XXXXX is the serial number of the indicator.



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEEn

I bAtt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN1

2 CoN2

3 CoN3

4 CoN4

5 uSb

6 rAd io

7 Eth

8 bLE

9 AdUAnC

1 obrF


2 obbLE

3 tErN


4 iGnorE

5 zEr.Str


Choose the printout line terminator character



Ignore unknown commands



Activates the zero "ZR" status indicator in the communication string. ZR replaces the ST status when weight is in zero range and stable (when the →0← annunciator is on). See page 127 for string descriptions.






How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 54	← =	

- A CAL
- B O.CAL
- C GRAU
- D SERIAL
- E LAYout**
- F LEVEL 1 LANG
- G FILTER 2 CHAR
- H SCREEN 3 hEAdEr
- I bAtE 4 dAtA
- J AutoFF 5 WEIGHs
- K rENotE 6 t.cREt
- L An.out 7 dt.ForN
- M inPutS 8 tN.ForN
- N outPut 9 CLoCh
- O rESEt 10 bArC.39
- P d.iAG 11 bArC.uP
- Q AdUAnC 12 bArC.L
- 13 bArC.h
- 14 bArC.dt
- 15 CoP.iES
- 16 End.t.c
- 17 b.L inE
- 18 LABEL
- 19 LB.SAVE
- 20 t.ESt

Parameters for ticket/label mode



- \* The type of AUTOMATIC data that prints depends on configuration:
  - Piece counting items include PCS and APW.
  - Checking weighing items include T.MAX, TARGET, T.MIN, UNDER, OK and OVER.
  - ID1 and ID2 are only included if the ID numbers are enabled.

**NOTE:** If the alibi memory option is enabled, weighing data is automatically added to the receipt /label.





# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit




Page 54

- A
- B
- C
- D
- E  →
- F 
  - 1
  - 2
  - 3
  - 4
  - 5
  - 6
  - 7
  - 8
  - 9
  - 10
  - 11
  - 12
  - 13
  - 14
  - 15
  - 16
  - 17
  - 18
  - 19
  - 20

## LANg

## Language Settings

Select the desired language



- EnG
- dEu
- FrAn
- ESPA
- Port
- GrEE
- PolSh
- iAL



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

- A **CAL**
- B **D.CAL**
- C **GRAU**
- D **SERIAL**
- E **LAYOUT**
  - F **LEVEL**
    - 1 **LANG**
    - 2 **CHAR**
      - 3 **HEAdEr**
        - 1 **CHAR 1**
        - 2 **CHAR 2**
      - 4 **DATA**
    - 5 **BE GHS**
    - 6 **Et CREt**
    - 7 **CLoCh**
    - 8 **bArC.39**
    - 9 **bArC.uP**
    - 10 **bArC.L**
    - 11 **bArC.h**
    - 12 **bArC.dt**
    - 13 **CoP.iES**
    - 14 **End.t iC**
    - 15 **b.L inE**
    - 16 **LABEL**
    - 17 **LB.SAUE**
    - 18 **tEst**

## CHAR

## Character Settings

Font dimensions


E-2-1

**CHAR 1**

Main font

Label mode

Ticket mode



**CHAR 2**

E-2-2

**CHAR 2**

See CHAR 1

### Additional parameter details:

To differentiate information in print, this parameter provides text with two different character dimensions with `CHAR 1` or `CHAR 2`. The character dimensions for each of the following print lines can be configured:

- Line 1 Header
- Line 2 Header
- Line 3 Header
- Line 4 header
- Body (GROSS, TARE, NET, etc)

For example:

1. Mode is set as `TPR`, `PRBO`, or `LABEL` (see **D-1-1**, **D-2-1**, **D-3-1**, **D-5-1**, **D-6-2**, **D-7-1** or **D-8-2**).
2. Four heading lines are required where the first two are double the height double the height of other text (second two and GROSS, TARE, NET, DATE and TIME):
  - `LINE 1 = CHAR 2 (E-3-2)`
  - `LINE 2 = CHAR 2 (E-3-2)`
  - `LINE 3 = CHAR 1 (E-3-2)`
  - `LINE 4 = CHAR 1 (E-3-2)`

Configure the font as the following:

- `CHAR 1` = Font 3
- `CHAR 2` = Font 3d

Result:

Dimension = `CHAR 2`


Dimension = `CHAR 1`



How to enter	How to browse	How to save and exit
1. Off	↑ =	 <i>Page 54</i>
2. On	↓ =	
3.	→ =	
<i>Page 54</i>	← =	

A	CAL	
B	D.CAL	
C	GrAU	
D	SERIAL	
E	LAYout	
F	LEVEL	1 LANG
G	FILtEr	2 CHAr
H	SCrEEr	3 hEAdEr
I	bAtt	4 dAtA
J	AutOFF	5 WEIGHs
K	rENotE	6 tICREt
L	An.out	7 dt.ForA
M	inPutS	8 tA.ForA
N	outPut	9 CLoCh
O	rESEt	10 bArC.39
P	dIAG	11 bArC.uP
Q	AdUAnC	12 bArC.L
		13 bArC.h
		14 bArC.dt
		15 CoP.IES
		16 End.tIC
		17 b.L inE
		18 LABEL
		19 LB.SAVE
		20 tEST

Enables header printing



EnAbLE parameter details:

- **no** = Disabled
- **YES** = Prints the header. If totalisation mode is active, prints on single totalisation ticket
- **totAL** = If totalisation mode is active, prints on total ticket
- **ALWAYS** = If totalisation mode is active, prints on total and single tickets

*How to enter*

- Off
- On
- 

*How to browse*

- =
- =
- =
- = /

*How to save and exit*

*Page 54*

A **CAL**

B **OCAL**

C **GRAU**

D **SERIAL**

E **LAYOUT**

F **LEVEL** 1 **LANG**

G **FILTER** 2 **CHAR**

H **SCREEN** 3 **HEADER**

I **BATT** 4 **DATA** 1 **ENABLE**

J **AUTOFF** 5 **BEHVS** 2 **LINE 1**

K **RENOTE** 6 **TECT** 3 **LINE 2**

L **ANOUT** 7 **DEFOR** 4 **LINE 3**

M **INPUTS** 8 **ENFOR** 5 **LINE 4**

N **OUTPUT** 9 **LOCAL**

O **RESET** 10 **BARC39**

P **DIAG** 11 **BARCUP**

Q **ADVANC** 12 **BARCL**

13 **BARCh**

14 **BARCLdt**

15 **COPIES**

16 **ENDTIC**


17 **BLINE**

18 **LABEL**

19 **LSAVE**

20 **TEST**

## Select character dimension



- Lines 3 and 4 are available after lines 2 are 3 are consecutively populated.
- (\*) Refer to table for the complete list of characters. Repeat the operation to program **LINE 2**, **LINE 3** and **LINE 4**. Select **no** to disable them.

(\*) List of characters

32		47	/	62	>	77	M	92	\	107	k	122	z
33	!	48	0	63	?	78	N	93	]	108	l	123	{
34	"	49	1	64	@	79	O	94	^	109	m	124	
35	#	50	2	65	A	80	P	95	_	110	n	125	}
36	\$	51	3	66	B	81	Q	96	'	111	o	126	~
37	%	52	4	67	C	82	R	97	a	112	p		
38	&	53	5	68	D	83	S	98	b	113	q		
39	'	54	6	69	E	84	T	99	c	114	r		
40	(	55	7	70	F	85	U	100	d	115	s		
41	)	56	8	71	G	86	V	101	e	116	t		
42	*	57	9	72	H	87	W	102	f	117	u		
43	+	58	:	73	I	88	X	103	g	118	v		
44	,	59	;	74	J	89	Y	104	h	119	w		
45	-	60	<	75	K	90	Z	105	i	120	x		
46	.	61	=	76	L	91	[	106	j	121	y		



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =


How to save and exit



Page 54

- A **CAL**
- B **DCAL**
- C **GRAU**
- D **SERIAL**
- E **LAYOUT**
  - F **LEVEL**
    - 1 **LANG**
    - G **FILTER**
      - 2 **CHAR**
      - H **SCREEN**
        - 3 **HEADER**
          - I **BATT**
            - 4 **DATA**
              - 1 **ENABLE**
              - J **AUTOFF**
                - 5 **BEIGHS**
                  - 2 **LINE1**
                  - K **RENOTE**
                    - 6 **TEXT**
                      - 3 **LINE2**
                      - L **ANOUT**
                        - 7 **DEFOR**
                          - 4 **LINE3**
                          - M **INPUTS**
                            - 8 **ENFOR**
                              - 5 **LINE4**
                              - N **OUTPUT**
                                - 9 **LOCAL**
                                - O **RESET**
                                  - 10 **BARC39**
                                  - P **DIAG**
                                    - 11 **BARCUP**
                                    - Q **ADVANC**
                                      - 12 **BARCL**
                                      - 13 **BARCh**
                                      - 14 **BARCdt**
                                      - 15 **COPIES**
                                      - 16 **ENDTIC**
                                      - 17 **BLINE**
                                      - 18 **LABEL**
                                      - 19 **LB.SAVE**
                                      - 20 **TEST**

## Programming example



How to set the value

- 
- 
- 
- 
- or
- 
- 
-



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit




Page 54

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P
- Q
- 
- 
- 
- 
- 
- 
- 
- 

## dAtA

### Data Settings


Select the weight data



## WEIGHs

### Weight Settings

Configure progressive weighs




WEIGHs parameter details:

- **no** = Disabled
- **YES** = Prints the weigh progressive number. If totalisation mode is active, prints on single totalisation ticket only
- **SuA** = If totalisation mode is active, prints on total ticket only
- **ALWAYS** = If totalisation mode is active, prints on total and single totalisation tickets












How to enter

- 1. Off 
- 2. On 
- 3. 

 Page 54

How to browse

-  = 
-  = 
-  = 
-  = 

How to save and exit




 Page 54

- A
- B
- C
- D
- E
- F  1
- G  2
- H  3
- I  4
- J  5
- K  6
- L  7
- M  8
- N  9
- O  10
- P  11
- Q  12
- 13
- 14
- 15
- 16
- 17
- 18
- 19
- 20

## t iCrEt Ticket Settings

Configure Ticket/label progressive number (1 to 99.999)

 Visible only if ModE = tPr or Pr80 (D-1-1, D-2-1, D-3-1, D-5-1, D-7-1 or D-8-2).




t iCrEt parameter details:

- no = Disabled
- YES = Prints the ticket progressive number. If totalisation mode is active, prints on single totalisation ticket only
- SuA = If totalisation mode is active, prints on total ticket only
- ALWAYS = If totalisation mode is active, prints on total and single totalisation tickets

## dt .ForA Date Format

Select the date format





# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit




Page 54

- A
- B
- C
- D
- E  →
- F  1
- G  2
- H  3
- I  4
- J  5
- K  6
- L  7
- M  8
- N  9
- O  10
- P  11
- Q  12
- 13
- 14
- 15
- 16
- 17
- 18
- 19
- 20


## tA.ForA Time Format

Select the date format



## CLoCh Clock Settings

Print date and time




CLoCh parameter details:

- no = Disabled
- YES = Print date and time. If totalisation mode is active, prints on single totalisation ticket only
- SuA = If totalisation mode is active, prints on total ticket only
- ALWAYS = If totalisation mode is active, prints on total and single totalisation tickets

| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           | <br>Page 54          |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =           |                      |

- A **CAL**
- B **OCAL**
- C **GRAU**
- D **SERIAL**
- E **LAYout** →
- F **LEVEL** 1 **LANG**
- G **FILtEr** 2 **CHAR**
- H **SCrEEEn** 3 **hEAdEr**
- I **bAtt** 4 **dAtA**
- J **AutOFF** 5 **WEIGHs**
- K **rENotE** 6 **tICREt**
- L **An.out** 7 **dt.FoRn**
- M **inPutS** 8 **tN.FoRn**
- N **outPut** 9 **CLoCh**
- O **rESEt** 10 **bArC.39**
- P **dIAG** 11 **bArC.uP**
- Q **AdUAnC** 12 **bArC.L**
- 13 **bArC.h**
- 14 **bArC.dt**
- 15 **COPIES**
- 16 **End.tIC**
- 17 **bLinE**
- 18 **LABEL**
- 19 **LB.SAUE**
- 20 **tEst**

Bar code 39




**bArC.39** parameter details:


- **no** = Disabled
- **YES** = Print a Code 39 barcode. If totalisation mode is active, prints on single totalisation ticket only
- **SuN** = If totalisation mode is active, prints on total ticket only
- **ALWAYS** = If totalisation mode is active, prints on total and single totalisation tickets

**NOTE:** Barcodes are always printed on the bottom of the ticket. The weight value in barcode format is expressed as 6 digits without decimal a point and with non-significant zeroes if needed to complete the 6 digit format.

**bArC.uP** Barcode Top Margin Settings



**bArC.L** Barcode Left Margin Settings





# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit




Page 54

- A
- B
- C
- D
- E 
  - F 
    - 1
    - G 
      - 2
      - H 
        - 3
        - I 
          - 4
          - J 
            - 5
            - K 
              - 6
              - L 
                - 7
                - M 
                  - 8
                  - N 
                    - 9
                    - O 
                      - 10
                      - P 
                        - 11
                        - Q 
                          - 12
                          - 13
                          - 14
                          - 15
                          - 16
                          - 17
                          - 18
                          - 19
                          - 20

## bArC.h Barcode Height Settings

Barcode height (mm)



Visible only if bArC.39 is active

Default = 10


If ModE=t iChEt (1...99)

If ModE=LABEL (0...255)

## bArC.dt Barcode Weight Data Settings


Selection of the weight data

Visible only if bArC.39 (E-10) is active.



## CoP iES Printed Copy Quantity

Multiple printed copies



The printer prints the quantity of copies defined in a collated order.


|  |   |  |
|--|---|--|
| <p><i>How to enter</i></p> <p>1. Off </p> <p>2. On </p> <p>3. </p> <p> Page 54</p> | <p><i>How to browse</i></p> <p> = </p> <p> = </p> <p> = </p> <p> = </p> | <p><i>How to save and exit</i></p> <p></p> <p> Page 54</p> |
|--|---|--|

- A CAL
- B D.CAL
- C GrAU
- D SEr iAL
- E **LAYout**
  - 1 LAnG
  - 2 CHAr
  - 3 hEAdEr
  - 4 dAtA
  - 5 WE iGHS
  - 6 t iCfEt
  - 7 dt .ForA
  - 8 tA.ForA
  - 9 CLoCh
  - 10 bArC.39
  - 11 bArC.uP
  - 12 bArC.L
  - 13 bArC.h
  - 14 bArC.dt
  - 15 CoP iES
  - 16 **End.t iC**
  - 17 **b.L iNt**
  - 18 LABEL
  - 19 LB.SAVE
  - 20 tEst

This parameter configures the end of the printout:

- For thermal printers (**D-1-1**, **D-2-1**, **D-3-1**, **D-5-1**, **D-6-2**, **D-7-1** or **D-8-2** *ModE = tPr* or *Pr80*), 2 empty lines are included at the end of the printout. This allows the ticket to exit the print head.
- For labelers (**D-1-1**, **D-2-1**, **D-3-1**, **D-5-1**, **D-6-2**, **D-7-1** or **D-8-2** *ModE = LABEL*), the instrument sends the end of label command to the labeler.

Paper outlet for end of ticket/receipt




*End.t iC* parameter details:

- no* = Disabled
- YES* = Add the end of ticket space - Label ends after each print. If totalisation mode is active, end ticket/label after each single totalisation ticket
- SuA* = If totalisation mode is active, end ticket/label after total prinout
- ALWAYS* = If totalisation mode is active, end ticket/label prints on total and single totalisation tickets

**b.L iNt Start of Ticket Configuration**



Print head preheating line (thermal printer only)

For Ticket mode only *ModE = tPr* or *Pr80* (**D-1-1**, **D-2-1**, **D-3-1**, **D-5-1**, **D-6-2**, **D-7-1** or **D-8-2**). To preheat the thermal printer head, a blank line can be included at the beginning of each printout.



| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           |                      |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =  /        |                      |

- A CAL
- B DCAL
- C GRAU
- D SERIAL
- E **LAYOUT**
- F LEVEL
  - 1 LANG
- G FILTER
  - 2 CHAR
- H SCREEN
  - 3 HEADER
- I BATT
  - 4 DATA
- J AUTOFF
  - 5 HEIGHT
- K RENOTE
  - 6 LABEL
- L AN.out
  - 7 dt.Forn
- M INPutS
  - 8 dt.Forn
- N outPut
  - 9 CLoCh
- O RESEt
  - 10 bArC.39
- P d iAG
  - 11 bArC.uP
- Q AdUAnC
  - 12 bArC.L
  - 13 bArC.h
  - 14 bArC.dt
  - 15 CoP iES
  - 16 End.t iC
  - 17 bL inE
  - 18 **LABEL**
  - 19 Lb.SAVE
  - 20 tEst





# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

- A **CAL**
- B **OCAL**
- C **GRAU**
- D **SERIAL**
- E **LAYOUT** →
- F **LEVEL** 1 **LANG**
- G **FILTER** 2 **CHAR**
- H **SCREEN** 3 **HEADER**
- I **BATT** 4 **DATA**
- J **AUTOFF** 5 **DEGHS**
- K **RENOTE** 6 **TCRET**
- L **ANOUT** 7 **dt.FORn**
- M **INPUTS** 8 **EN.FORn**
- N **OUTPUT** 9 **CLoCh**
- O **RESET** 10 **bARc.39**
- P **diag** 11 **bARc.uP**
- Q **ADUANC** 12 **bARc.L**
- 13 **bARc.h**
- 14 **bARc.dt**
- 15 **CoP.iES**
- 16 **End.t.c**
- 17 **b.L.inE**
- 18 **LABEL**
- 19 **Lb.SAVE**
- 20 **tEST**

## Lb.SAVE Label Save


Saves labels in printer memory. If the label is saved successfully, the labeler produces an auditory confirmation and causes the LEDs to blink briefly.



**NOTE:** This parameter must be executed when using a labeler. Labels must be saved when changes are completed, otherwise changes will be lost.




Visible only if *ModE* = *LABEL* (D-1-1, D-2-1, D-3-1, D-5-1, D-6-2, D-7-1 or D-8-2).



## tEST Test print

Produces a test print for a labeler or printer. For labels, the last label saved with *Lb.SAVE* is tested. For printers, the current configuration is tested.





# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit



Page 54

A CAL

B DCAL

C GRAU

D SERIAL

E LAYout

F LEVEL

G FILTER

H SCREEN

I bAtt

J AutoOFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG


Q AdVAnC

- 1 Port
- 2 FCALC
- 3 ZErO
- 4 FILTER
- 5 L iM it

## LEVEL F. Inclinometer Configuration

### Port Port Configuration

Product not legal for trade.





| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           | <br>Page 54          |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =           |                      |




- A **CAL**
- B **O.CAL**
- C **GrAU**
- D **SERIAL**
- E **LAYout**
- F **LEVEL** →
- G **FILtEr** 1 **Port**
- H **SCrEEEn** 2 **FCALC**
- I **bAtt** 3 **ZEro**
- J **AutoFF** 4 **FILtEr**
- K **rENotE** 5 **L iM it**
- L **An.out**
- M **inPutS**
- N **outPut**
- O **rESEt**
- P **d iAG**
- Q **AdUAnC**

Product not legal for trade.

FCALC requires measuring each side of an object with an inclinometer attached to complete calibration. The following is an example of the sides that would be measured on a object.



Visible only if Port ≠ oFF.





# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit









Page 54

- A CAL
- B DCAL
- C GRAU
- D SERIAL
- E LAYOut
- F LEVEL
- G Filter
  - 1 Port
  - 2 FCALC
  - 3 ZERO
  - 4 Filter
  - 5 Limit
- I bAtt
- J AutoOFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdVAnC

Displays the current inclination value. Measure all sides (the order of sides does not matter). Repeat the measurement for each side (4).

**NOTE:** Sides may be measured in any order. This example measures the sides consecutively.



Optional, if additional equalization is required, repeat the procedure to complete measurements for all sides (4) for the next configured equalization point (up to 9).

**NOTE:** All equalization points must be a different inclination value.



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr iAL

E LAYout

F LEVEL

G F iLteR

H SCrEEEn

I bAtte

J AutoFF

K rENotE

L An.out


M inPutS

N outPut

O rESEt

P d iAG

Q AdvARnC




1 Port

2 FCALC

3 zEro

4 F iLteR

5 L iM it



1 dEG

2 PErc

## zEro Zero Settings

Acquisition of the zero point of inclination.

Visible only if Port ≠ oFF.


Product not legal for trade.



## F iLteR Filter Settings

Configures data collection speed from the module in hertz (F 1.00 - 5.00).


Visible only if Port ≠ oFF.




## L iM it Limit Settings












Tilt limit setting

Set the value in degrees (it is automatically converted to percentages)



Set the value as a percentage (it is automatically converted to degrees)




| How to enter   | How to browse   | How to save and exit  |
|--|---|---|
| 1. Off  | ↑ =    |  |
| 2. On   | ↓ =    |   |
| 3.      | → =    |   |
|  Page 54 | ← =  /  |   |
|  |  Page 54   |   |

- A CAL
- B O.CAL
- C GrAU
- D SEr AL
- E LAYout
- F LEVEL
- G **F ILtEr** →
- H SCrEEr 1 F 1
- I bAtE 2 F 2
- J AutoFF 3 F 3
- K rENotE 4 F 4
- L An.out 5 F 5
- M inPutS 6 F 6
- N outPut 7 F 7
- O rESEt 8 F 8
- P d iAG 9 CUsToN
- Q AdUAnC

## F ILtEr G. Weighing filters










To change the responsiveness of the scale. This is useful to adjust the scale according to your needs.



 With an approved instrument, it is not possible to change the filter.

“F B” represents the lowest filtering incidence.

By increasing the incidence, the weight becomes more stable.

It is advisable to carry out several weighing operations by changing the incidence until the best compromise between responsiveness and stability is achieved.

- |            |               |                             |  |
|------------|---------------|-----------------------------|--|
| <b>G-1</b> | <b>F 1</b>    | Filter at 5 Hz.             |  |
| <b>G-2</b> | <b>F 2</b>    | Filter at 10 Hz.            |  |
| <b>G-3</b> | <b>F 3</b>    | Filter at 20 Hz.            |  Standard filter  |
| <b>G-4</b> | <b>F 4</b>    | Filter at 40 Hz.            |   |
| <b>G-5</b> | <b>F 5</b>    | Filter at 80 Hz.            |   |
| <b>G-6</b> | <b>F 6</b>    | Filter at 160 Hz.           |   |
| <b>G-7</b> | <b>F 7</b>    | Filter at 325 Hz.           |   |
| <b>G-8</b> | <b>F 8</b>    | Filter at 650 Hz.           |   Only visible if n.ChAn < 3 |
| <b>G-9</b> | <b>CUsToN</b> | Configured with XSpeed Tool |  |

 **NOTE:** Filters **F 3** through **F 8** are filters suitable for legal for trade applications. 



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit




Page 54

- A CAL
- B O.CAL
- C GRAV
- D SERIAL
- E LAYOUT
- F LEVEL
- G FILTER
- H SCREEN
- I BATT
- J AUTOFF
- K REMOTE
- L AN.OUT
- M INPUTS
- N OUTPUT
- O RESET
- P DIAG
- Q ADVANC

- 1 BAKLIT
- 2 BRGHT
- 3 LOCK
- 4 COLOUR
- 5 DSP.F


## SCREEN H. Adjusting the Display

### BAKLIT Backlight settings




Auto turns backlight ON when weight is unstable and turns OFF when weight becomes stable for at the configured time in seconds.

### br ght Brightness Settings



### LoCh Lock Settings

Locks display with message “-PL .H-” when the indicator is a slave unit in a multiple scale master-slave legal for trade system. “H” is the scale number (485 address). This function locks the keyboard as well. Press ZERO key and then ENTER key to unlock. A scrolling message lists this procedure.





# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit




Page 54


- A CAL
- B DCAL
- C GrAU
- D SEr iAL
- E LAYout
- F LEVEL
- G FILTER
- H SCrEEen
- I bAtte
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdUAnC

- 1 bAtte
- 2 br iGht
- 3 LoCh
- 4 CoLour
- 5 dSP.rF

## CoLour Backlight Color Settings



## dSP.rF Display Refresh Rate Settings



**NOTE:** The refresh rate affects how frequently the display refreshes. The lowest refresh rate 1 hertz, improves display stabilization for high frequency applications. Conversely, the fastest refresh rate *nor n.* (30 hertz), causes the screen to be more reactive and is useful for less demanding applications.

# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =


How to save and exit



Page 54


- A CAL
- B O.CAL
- C GrAU
- D SEr iAL
- E LAYout
- F LEVEL
- G F iLTER
- H SCrEEr
- I **bAtt**
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdUAnC

## bAtt I. Battery Power Supply



**WARNING:** Only use original rechargeable batteries.

## AutoFF J. Auto Switch-off



This step disables or enables automatic indicator power off (1 to 255 minutes). The automatic power off function initiates when an unloaded scale is not disturbed for the configured time value. The display blinks -oFF- and an acoustic tone is emitted as the indicator turns off.

If the scale is disturbed (weight placed on the scaled or keys pressed) the automatic power off function cancels.



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit




Page 54

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K 
  - 1
  - 2
- L
- M
- N
- O
- P
- Q

## rENotE K. Remote Control

### EnAb Remote Control Settings




6-Key radio-frequency remote control. All keys perform tare.

6-Key radio-frequency remote control. Multi-function mode.

6-Key radio-frequency remote control in broadcast mode. All keys perform tare.

6-Key radio-frequency remote control in broadcast mode. Multi-function mode.

### Port Remote Control Port Settings



For remote control pairing information, see the DFWX Series User manual.



NOTE: For more information about the external module see, page 46.





How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =


How to save and exit



Page 54

- A CAL
- B DCAL
- C GRAU
- D SERIAL
- E LAYOut
- F LEVEL
- G FILTER
- H SCREEN
- I bAtt
- J AutoFF
- K rENotE
- L **An.out**
  - M inPutS 1 nEt
  - N outPut 2 Pnt.und
  - O rESEt 3 Hgt.1
  - P d iAG 4 Pnt.1
  - Q AdvAnC 5 Hgt.2
  - 6 Pnt.2
  - 7 Hgt.3
  - 8 Pnt.3
  - 9 Pnt.oUr

Operation proportional to net/gross weight



**NOTE:** Due to the real-time output, It is possible to check the configured value with a digital volt meter (see example on page 106).

**NOTE:** For parameter configuration values, view the indicative values in the following table.

# MENU

**How to enter**

- 1. Off
- 2. On
- 3.


**How to browse**

- =
- =
- =
- =

**How to save and exit**

*i* Page 54 *i* Page 54


- A CAL
- B D.CAL
- C GrAU
- D SErIAL
- E LAYout
- F LEVEL
- G F ILtEr
- H SCrEEEn
- I bAtT
- J AutoFF
- K rENotE
- L An.out
- M inPutS
  - 1 nEt
- N outPut
  - 2 Pnt.und
- O rESEt
  - 3 Hgt.1
- P d IAG
  - 4 Pnt.1
- Q AdVAnC
  - 5 Hgt.2
  - 6 Pnt.2
  - 7 Hgt.3
  - 8 Pnt.3
  - 9 Pnt.oUr




| Value to be entered | Output Volts | Output mA |
|---------------------|--------------|-----------|
| 1200                | ~ 0 V        | ~ 0 mA    |
| 11250               |              | ~ 4 mA    |
| 52200               |              | ~ 20 mA   |
| 62300               | ~ 10 V       |           |

Programming example:

This example displays how to set up 10V at 1000kg.



Enter **62300** (the reference value given in the table) and check the analogue output using a tester.



*i* NOTE: Continue procedure on following page.

# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit




Page 54


- A CAL
- B DCAL
- C GrAU
- D SEr AL
- E LAYout
- F LEVEL
- G F ILtEr
- H SCrEEr
- I bAtE
- J AutoFF
- K rENotE
- L An.out
- M inPutS
  - 1 nEt
  - 2 Pnt.und
  - 3 Hgt.1
  - 4 Pnt.1
  - 5 Hgt.2
  - 6 Pnt.2
  - 7 Hgt.3
  - 8 Pnt.3
  - 9 Pnt.oUr
- N outPut
- O rESEt
- P d iAG
- Q AdUAnC
  - 1 inP.b.1
  - 2 inP.b.2

Adjust the analogue output by increasing or decreasing the value. Minimum variations of at least 10 points are recommended, (623 10, 62320, 62330, etc.)

How to set the value




The output is updated in real-time.



Once the desired adjustment has been made, confirm the value with .

## inPutS M. Digital inputs

### inP.b.1 Input configuration 1



NOTE Repeat the same operation for inP.b.2.

| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           |                      |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =  /        |                      |


|   |        |
|---|--------|
| A | CAL    |
| B | OCAL   |
| C | GrAU   |
| D | SERIAL |
| E | LAYout |
| F | LEVEL  |
| G | FILtEr |
| H | SCrEEr |
| I | bAtt   |
| J | AutoFF |
| K | rENotE |
| L | An.out |
| M | inPutS |
| N | outPut |
| O | rESEt  |
| P | dIAG   |
| Q | AdUAnC |

|   |         |   |        |
|---|---------|---|--------|
| 1 | rEL.b.1 | 1 | FunCt  |
| 2 | rEL.b.2 | 2 | ModE   |
| 3 | rEL.b.3 | 3 | dirECt |
| 4 | rEL.b.4 | 4 | hIStEr |
| 5 | rEL.b.5 | 5 | CoLoR  |
| 6 | rEL.b.6 |   |        |

**outPut N. Digital Outputs**


Operation on net weight, gross weight or batching



**i** **NOTE:** For dosing / filling:  
 • Activate mode **doSAGE**  
 • Set tare **unLoCk**

The output is activated only after the container has been calibrated (by key or external button) and is deactivated when the set target (setpoint) is reached. To carry out two-speed filling, two outputs must be programmed with **doSAGE** mode.

Normally open (**n.o.**) or closed (**n.c.**) operation.



How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B DCAL

C GRAU

D SERIAL

E LAYOut

F LEVEL

G FILTER

H SCREEN

I bAtt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdvAnC

1 rEL.b.1

2 rEL.b.2

3 rEL.b.3

4 rEL.b.4

5 rEL.b.5

6 rEL.b.6

1 Funct


2 ModE

3 d irECT

4 h iStEr

5 CoLoR

Output activation mode




When a point is reached, outputs activates regardless if weight is stable or unstable

Only at stable weight


Double threshold operation

(activation weight threshold  $\neq$  from deactivation weight threshold)

Visible only if Funct (N-1-1) = GroSS or rEt.




Operation:



NOTE: Repeat the same operation for rEL .b.2, rEL .b.3, rEL .b.4, rEL .b.5 and rEL .b.6.  
For more information about hysteresis, see page 33.

Color operation



- CoL 1 = Red
- CoL 2 = Green
- CoL 3 = Yellow
- CoL 4 = Blue
- CoL 5 = Purple
- CoL 6 = Orange
- CoL 7 = Teal



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEr

I bAtt

J AutoFF

K rENotE

L An.out


M inPutS

N outPut


O rESEt

P d iAG

Q AdUAnC



## rESEt O. Factory Configuration Reset



Function for restoring default configurations keeping the stored calibration.

## d iAG P. Diagnostics

P-1 AdC.uU

Converter or load cell test. Check of input signal in  $\mu\text{V}$ . In case of multiple equalised channels, press buttons or to examine all the channels selected.

P-2 d iSPLA

Display. Integrity check of all segments and icons.

P-3 rEYb

Keypad. Press any key to check its correct operation, with beep and code on display. Press same key three times consecutively to exit.

P-4 CtS

CTS. Check of status of the control signal from the printer.

P-5 outPut



**WARNING: Before entering the outPut step, ensure activating the output does not cause danger to people, animals or property.**



Optional digital outputs. Check the activation and deactivation of each contact.

*Example: out 1 activates output 1. Press button to select the next output.*

P-6 inPutS



Optional digital inputs. Check the activation and deactivation of each input.

*Example: i.b +0 input not active*

*Example: i.b +1 active input*

Press button to select the next input.

P-7 An.out



Analogue output. Enter the digital value and check the analogue output response with a multi-meter

P-8 SEr.nuN

Scale serial number.

P-9 PrG.UEr

Reviewing hardware (e.g. rEU 5) followed by software version (e.g. 04.00.00).

P-10 d iU.int

Number of ADC conversion points per internal scale division. Typically, for accurate and stable results it is recommended to be about 50.

To increase this number, decrease the scale intervals (from 10000d to 3000d) or reduce the load cell capacity.



# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr iAL

E LAYout

F LEVEL

G F iLteR

H SCrEEr

I bAtE

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 AdC.vU

2 d iSPLA

3 rEyb

4 CtS

5 outPut

6 inPutS

7 An.out

8 SEr.nuM

9 PrG.UEr

10 d iL.int

11 AdC.Pnt

12 bt.AdC

13 Ph.AdC

14 LEVEL

15 EthErn

16 MAC.Add

P-11 AdC.Pnt

Converter test. Checks signal in ADC points. In case of multiple equalised channels, press buttons or to examine all the channels selected.

P-12 bt.AdC

Battery voltage and current charge percentage.

P-13 Ph.AdC

Mains power supply voltage value.

P-14 LEVEL

Shows the inclinometer side and current angle.



P-15 EthErn

Displays Ethernet board firmware version.

P-16 MAC.Add

Displays the LAN MAC address of the module



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54

How to browse

- =
- =
- =
- = /

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr iAL

E LAYout

F LEUEL

G F iLteR

H SCrEEen

I bAtte

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdVAnC

1 CAL.PAr

2 EQUALP

3 CAL.AdU

4 Stb.FLt

5 PEAK.FL

6 NEtrol

7 t iLte

9 rEAct

9 LoCk.Fb

10 bu22Er

11 AL iB i.r

12 P in.tEC

13 P in.uSE

14 dFLt.t

1 DEC iN

2 d iU

3 u.n.

4 rAnGE 1

5 rAnGE 2

6 rAnGE 3


7 EQUAL

8 n.ChAn


## AdVAnC Q. Advanced

### CAL.PAr Calibration parameters

Decimal point position (0...3)



Division (scale resolution)



NOTE: in the case of a multi-range and multi-interval scale, the division of second and third ranges are automatically set.





# MENU

How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr AL

E LAYout

F LEUEL

G F ILtEr

H SCrEEr

I bAtE

J AutOFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d rAG

Q AdvAnC

1 CAL.PAr

2 EQUAL.P

3 CAL.AdU

4 StEb.FLt

5 PErF.FL

6 NEtrol

7 t ILt

8 rEACT

9 LoCh.Fb

10 bu22Er

11 AL ib.r

12 P in.tEC

13 P in.uSE

14 dFLt.t

1 dEC r

2 d iU

3 u.n.

4 rAnGEt


5 rAnGE 1

6 rAnGE2


7 EQUAL

8 n.ChAn

Unit of measure




Set multi-range or multi-interval (division)



NOTE: in the case of a multi-range and multi-interval scale, the division of second and third ranges are automatically set.

Scale capacity. Set Max or Range 1 (Max range = 030.000)




| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           |                      |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =  /        |                      |

- A CAL
  - B D.CAL
  - C GRAV
  - D SERIAL
  - E LAYOut
  - F LEVEL
  - G FILTER
  - H SCREEN
  - I bAtt
  - J AutoFF
  - K rENotE
  - L An.out
  - M inPutS
  - N outPut
  - O rESEt
  - P d.iAG
  - Q AdVAnC
- 
- 1 CAL.PAr
  - 2 EQuAL.P
  - 3 CAL.AdV
  - 4 Stb.FLt
  - 5 PEAK.FL
  - 6 NEtrol
  - 7 t iLt
  - 9 rEAct
  - 9 LoCh.Fb
  - 10 bu22Er
  - 11 AL ib i.r
  - 12 P in.tEC
  - 13 P in.uSE
  - 14 dFLt.t
- 
- 1 dEC iN
  - 2 d iU
  - 3 u.n.
  - 4 rAnGE 1
  - 5 rAnGE 2
  - 6 rAnGE 3
  - 7 EQuAL
  - 8 n.ChAn

Range 2 and Range 3


For multi-range scales, set the second weighing range.



Example of multi-range configuration at 1500/3000 kg, division 0,5/1 kg. Set:

dEC i = 0.0  
 d iU = 5  
 rAnGE 1 = 1500.0  
 rAnGE 2 = 3000.0


Equalisation function



**NOTE:** For more information see, wiring diagram on page 20 and equalisation procedure on page 115.

Equalised analogue channels

Only visible if EQuAL (Q-1-7) = YES



**NOTE:** The channel quantity may impact the weighing speed and reduce the filter selection list.


| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           |                      |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =           |                      |
|              | ○ =           |                      |

- A **CAL**
- B **OCAL**
- C **GRAU**
- D **SERIAL**
- E **LAYOUT**
- F **LEVEL**
- G **FILTER**
- H **SCREEN**
- I **bAtt**
- J **AutoFF**
- K **RENotE**
- L **An.out**
- M **inPutS**
- N **outPut**
- O **rESEt**
- P **dTAG**
- Q **AdVAnC**
  - 1 **CAL.PAr**
  - 2 **EQuALP**
    - 1 **E9.0**
    - 2 **E9.1**
    - 3 **E9.2**
    - 4 **E9.3**
    - 5 **E9.4**
  - 3 **CAL.AdV**
  - 4 **Stb.FLt**
  - 5 **PEAK.FL**
  - 6 **NEtrol**
  - 7 **tLt**
  - 8 **rEAct**
  - 9 **LoCh.Fb**
  - 10 **bu22Er**
  - 11 **ALibir**
  - 12 **PintEC**
  - 13 **PintSE**
  - 14 **dFLt.t**

**i** NOTE: **EQuAL.P** is only visible if the function **EQuAL (Q-1-7)** is activated in the menu **CAL.PAr (Q-1-1)**.

The equalisation wizard requests to acquire the zero point with scale unloaded and to later place a weight of about 1/8 of the maximum capacity (Max) on each individual cell in the required order. The message **E9.oh** will appear after the procedure.

Proceed with the calibration.



|       |                         |      |                   |
|-------|-------------------------|------|-------------------|
| Q-2-1 | <b>E9.0</b> → <b>OK</b> | -oh- |                   |
|       | <b>E9.1</b> ←           |      |                   |
| Q-2-2 | <b>E9.1</b> → <b>OK</b> | -oh- |                   |
|       | <b>E9.2</b> ←           |      | kg = 1/8 Max (kg) |
| Q-2-3 | <b>E9.2</b> → <b>OK</b> | -oh- |                   |
|       | <b>E9.3</b> ←           |      |                   |
| Q-2-4 | <b>E9.3</b> → <b>OK</b> | -oh- |                   |
|       | <b>E9.4</b> ←           |      |                   |
| Q-2-5 | <b>E9.4</b> → <b>OK</b> | -oh- |                   |
|       | <b>CAL.AdV</b> ←        |      |                   |



# MENU

How to enter

- 1. Off
- 2. On
- 3.

Page 54


How to browse

- =
- =
- =
- = /

How to save and exit



Page 54




## CAL.AdU Multi-point Calibration \ Linearization (1001 + F)

**NOTE:** Before calibrating, configure the decimals (*dEC i* - Q-1-1), the division (*d iU* - Q-1-2) and the capacity (*rAnGE* - Q-1-5 and Q-1-6).

**NOTE:** For more information about zero and span acquisition, see page 126.


Start of the calibration procedure:



| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           | <br>Page 54          |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =           |                      |


- A CAL
- B D.CAL
- C GRAV
- D SERIAL
- E LAYOUT
- F LEVEL
- G FILTER
- H SCREEN
- I BATT
- J AUTOFF
- K REMOTE
- L AN.OUT
- M INPUTS
- N OUTPUT
- O RESET
- P DIAG
- Q ADVANC
  - 1 CAL.PAR
  - 2 EQUALP
  - 3 CAL.ADV
  - 4 Stb.FLT
  - 5 PEAK.FL
    - 1 Stb.t.in
    - 2 n.in.VAr
  - 6 NETROL
  - 7 tilt
  - 8 REACT
    - 1 PF.LF.dU
    - 2 PF.LF.tn
    - 3 PF.d.U
    - 4 PF.bn.dU
    - 5 PF.t.inE
  - 9 LOCF.Fb
  - 10 buZZEr
  - 11 ALIB.r
  - 12 P.in.tEC
  - 13 P.in.vSE
  - 14 dFLt.t

### Stb.FLT Stability Filter (Internal Use Only)



Stability filter that locks the weight if it oscillates around a value for a maximum of 10 divisions. The weight is unlocked if the value increases/decreases for the number of divisions set in the parameter *n.in.VAr* for a time value greater than the time set in the parameter *Stb.t.in*.  
To disable *Stb.t.in*, set 0 to disable.

### PEAK.FL Anti-peak Filter (Internal Use Only)













*PF.LF.tn, PF.d.U, PF.bn.dU, PF.bn.dU, PF.t.inE* visible if *PF.LF.dU = 1 - 1000*

Filter that eliminates sudden weight peaks (for example, shocks or falling material). The weight is locked if it remains within the number of divisions set in *PF.LF.dU* or *PF.bn.dU* for the time set in *PF.LF.tn*.

The weight unlocks for a variety of reasons:


- The weight deviates from the division band defined in *PF.bn.dU* for the time set it *PF.t.inE*.
- The weight deviates from the locking value for a number of divisions set in *PF.d.U*.
- The time set in *PF.t.inE* elapses.

Configure *PF.LF.dU* as 0 to disable the function.


| How to enter   | How to browse   | How to save and exit  |
|--|---|---|
| 1. Off  | ↑ =    |  |
| 2. On   | ↓ =    |   |
| 3.      | → =    |   |
|  Page 54  | ← =  /  |   |


- A CAL
- B O.CAL
- C GrAU
- D SEr AL
- E LAYout
- F LEUEL
- G F ILtEr
- H SCrEEr
- I bAtt
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdVAnC
  - 1 CAL.PAr
  - 2 EQuALP
  - 3 CAL.AdU
  - 4 Stb.FLt
  - 5 PErF.FL
  - 6 NEtrol
    - 1 O.PErC
    - 2 d iU.Stb
    - 3 t iN.Stb
    - 4 Q.trH
    - 5 Q.trH.SP
    - 6 on.2ErO
    - 7 CAL.AdU
    - 8 CAL.NAn
    - 9 d.SALE
    - 10 rEN.dSP

ZERO key zeroing percentage




Sensitivity of the weight stability control



 **NOTE:** This is the division quantity the instrument uses to detect weight stability. Increased divisions leads to the less sensitivity, and consequently, stability is more easily detected.

Stability detection time (in milliseconds)



If the weight remains within the number of divisions set in *d iU.Stb* for the time set in this parameter, the weight is stable. In the case of an approved transmitter, the value is fixed at 500 ms.

### How to enter

1. Off
2. On
- 3.

Page 54

### How to browse

- =
- =
- =
- =

### How to save and exit



Page 54

A CAL

B 0.CAL

C GrAU

D SEr AL

E LAYout

F LEVEL

G F ILtEr

H SCrEEr

I bAtE

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdvAnC

1 CAL.PAr

2 EQUAL.P

3 CAL.AdU

4 Stb.FLt

5 PEER.FL

6 NEtroL

7 t iLt

9 rEAct

9 LoCh.Fb

10 buZZEr

11 AL ib i.r

12 P in.tEC

13 P in.uSE

14 dFLt.t

1 0.PErC

2 d iU.Stb

3 t iN.Stb

4 0.trr

5 0.trr.SP

6 on.2Er

7 CAL.AdU


8 CAL.NAn

9 d.SALE

10 rEN.dSP

## Zero tracking sensitivity


The number of stable scale division automatically zeroed by the time configured in the 0.trr.SP parameter.



NOTE: Legal for trade approved values are tr 1r4 are tr 1r2.




## Zero tracking speed (in milliseconds)



| How to enter | How to browse | How to save and exit |
|--------------|---------------|----------------------|
| 1. Off       | ↑ =           |                      |
| 2. On        | ↓ =           |                      |
| 3.           | → =           |                      |
| Page 54      | ← =  /        |                      |


- A CAL
- B O.CAL
- C GrAU
- D SEr iAL
- E LAYout
- F LEVEL
- G F iLteR
- H SCrEEr
- I bAtte
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdUANc
  - 1 CAL.PAr
  - 2 EQUALP
  - 3 CAL.AdU
  - 4 Stb.FLt
  - 5 PEAR.FL
  - 6 NEtrol
    - 1 O.PErC
    - 2 d iU.Stb
    - 3 t iN.Stb
    - 4 O.tRr
    - 5 O.tRr.SP
    - 6 on.ZErO
    - 7 CAL.AdU
    - 8 CAL.NAr
    - 9 d.SALE
    - 10 rEN.dSP

Start-up Auto Zeroing function and auto zeroing maximum percentage



\* = default value

Acquisition of a single calibration point (Zero, Span or intermediate point)



*i* Repeat the same operation for Po int. 1, Po int. 2 and Po int. 3.

*i* **NOTE:** It is possible to acquire or modify a single calibration point with this function. It can also be used to perform the first scale calibration. It is frequently used during silo calibration, as it acquires and stores the zero value and spans the value independently.

This function also allows modifying the scale decimal point position without performing a new calibration:

1. Modify the decimal point position in with dEc iN (Q-1-1).
2. Perform this step and modify the point value considering the new decimal point position.

For example: Perform the following to change from a calibration without decimal points to a calibration with 3 decimal points without acquiring the calibration points:

Set dEc iN to 0.000  
 If calibration point Point1 was 100 kg, you could modify it to 100.000 kg.



How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =

How to save and exit



Page 54

A CAL

B D.CAL

C GrAU

D SEr iAL

E LAYout

F LEUEL

G F iLteR

H SCrEEr

I bAtt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUANc

1 CAL.PAr

2 EQUALP

3 CAL.ADU

4 Stb.FLt

5 PEAr.FL

6 NEtroL

7 t iLt

9 rEACt

9 LoCh.Fb

10 bu22Er

11 AL ib i.r

12 P in.tEC

13 P in.vSE

14 dFLt.t

1 O.PErC

2 d iU.Stb

3 t iN.Stb

4 O.trH


5 O.trH.SP

6 on.2ErO

7 CAL.ADU


8 CAL.NAn

Manual calibration produced by ADC counts for a single calibration point













t iLt Tilt Sensor Management

NOTE: The tilt sensor is an optional device that detects if the inclination of the scale is greater than  $\pm 5\%$ . The tilt sensor must connect to the SENSOR port.




NOTE: If the indicator is approved, this step is read-only.

NOTE: The DFWX only accepts Dini Argeo Title Sensors.

| How to enter   | How to browse   | How to save and exit  |
|--|---|---|
| 1. Off  | ↑ =    |  |
| 2. On   | ↓ =    |   |
| 3.      | → =    |   |
|  Page 54 | ← =  /  |   |


- A
  - B
  - C
  - D
  - E
  - F
  - G
  - H
  - I
  - J
  - K
  - L
  - M
  - N
  - O
  - P
  - Q
- 1
  - 2
  - 3
  - 4
  - 5
  - 6
  - 7
  - 8
  - 9
  - 10
  - 11
  - 12
  - 13
  - 14



Reactivation of the print function. This function avoids accidental double execution of the same operation (printout or totalization).




**rEACT** parameter details:  
**zErO** = After unloading container/object NET weight must be zero.  
**inSt** = After executing a function, it reactivates after the weight becomes unstable and changes more than the divisions set in **n.d iUS** above.  
**ALWAYS** = Function always active

Permanent keypad lock (excluding key )



In user mode, to unlock the keyboard press \* followed by .

Enables or disables the instrument's buzzer.



How to enter

1. Off
2. On
- 3.

Page 54

How to browse

- =
- =
- =
- =


How to save and exit



Page 54


- A CAL
- B D.CAL
- C GrAU
- D SEr AL
- E LAYout
- F LEUEL
- G F ILtEr
- H SCrEEr
- I bAtE
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d IAG
- Q AdVAnC
  - 1 CAL.PAr
  - 2 EQUALP
  - 3 CAL.ADU
  - 4 StEb.FLt
  - 5 PEAA.FL
  - 6 NEtrol
  - 7 t ILt
  - 8 rEAct
  - 9 LoCk.Ab
  - 10 bu22Er
  - 11 AL ib ir
  - 12 P in.tEE
  - 13 P in.uSE
  - 14 dFLt.t

## Alibi memory reset




Only visible if alibi memory option is present  
 Reset is not possible if instrument is legal for trade

## Set PIN access to PIN protect programming menu




If PIN is lost, contact technical support for assistance.

## Set PIN access to PIN protect F Mode and Menu



If PIN is lost, contact technical support for assistance.

## Total reset of memory and of calibration, with reset of the factory settings.




NOTE: Once default function is executed, the indicator emits a chime for confirmation. To store the default values, exit setup and, press Enter when indicator prompts "SurEP". If confirmation is canceled, all the parameters remain without changes (including the calibration).

In case of legal for trade instrument, the default function does not affect calibration and metrological parameters.


Default function should be used after any firmware update to reset the instrument's memory.

## 29. FIRMWARE UPDATE

### Verify Firmware Version

 Visit [www.diniargeo.com](http://www.diniargeo.com) to review DFWX "Last Firmware Revision News" and determine the most current firmware version.

1. Restart the DFWX.
2. Press and hold ▲ when 888888 displays.
3. Release the ▲ button.
4. Select *PrG.UEr* from the *d iAG* menu.




5. Firmware version displays on the DFWX.

### Update Firmware


Requirements:

- Windows 10 or greater computer
- USB Type-C data cable
- Firmware update software


1. Download the firmware update software.
2. Open DFWX (see page **11**) and connect USB Type-C cable end to USB Type-C port in the DFWX (see page **20**).
3. Connect the free end of the USB cable to a Windows 10 or newer computer.
4. Power on the indicator.
5. Launch the firmware update executable.
6. In the firmware updater, select the COM port used by the computer. If needed, check the Windows Device Manager to verify which COM port is used by the indicator.
7. Enable the **Boot** check box.
8. Select the **Program** button.



9. The firmware update software briefly processes the update and then begins to update the firmware.





10. The firmware progress bar fills as the instrument is updated.



11. When firmware has been updated, the progress bar is filled and a success prompt displays.


12. Select **OK** to close the pop-up window.



13. Unplug the USB cable from the DFWX.

14. Power cycle the DFWX.

15. Default the device after the firmware upgrade is complete.



16. Reinstall back cover.

17. Calibrate and Setup the DFWX.


## 30. SILO CALIBRATION

Silo calibration is comprised of three different calibrations: Reference, Zero Acquisition, and Span Acquisition. Zero Acquisition and Span Acquisition can be completed at different instances. For example, it is not uncommon to complete Zero Acquisition and then Span Acquisition the following day.

### Reference Calibration

---

1. Empty the silo.
2. Power on the indicator, it displays `noCAL`.
- NOTE: If a zero calibration is stored, proceed to Span Calibration.**
3. Navigate to `CAL` and then press **OK**.
4. The indicator displays `d.U.`. Enter the desired scale resolution and then press **OK**.
5. The indicator displays `CAPAC`. Enter the desired scale capacity and then press **OK**.
6. The indicator displays `BALE`, `unLoad` and then `oF`. Zero acquisition is complete.
7. The indicator displays `CAL.Pnt`. Enter the weight of the calibration weight and then press **OK**.
8. Load the calibration on an empty area of the silo (do not fill) and then press **OK**.
9. The indicator calculates the zero calibration. When completed, it displays `CAL.oF`.
10. Save the configuration and exit the Technical Menu (see page 54).



### Span Acquisition

---

1. Turn on the indicator.
2. Fill the silo with material,
3. Enter shortcut `1002 + F`.
4. `CAL.AdU` displays.
5. Select `Po int . l` with **▲** and **▼** arrows.
6. Press **OK**. The indicator displays `BEIGHt`.
7. Enter the weight of the material inside the silo and then press **OK**.
8. The indicator acquires span and displays `CAL.oF` when completed.
9. The indicator returns to the weight display.



### Zero Acquisition

---

1. Turn on the indicator.
2. Empty the silo,
3. Enter shortcut `1003 + F`.
4. `0.CAL` and `SurEP` displays press **OK**.
5. The indicator acquires zero and displays `CAL.oF` when completed.
6. The indicator returns to the weight display.



## 31. COMMUNICATION STRINGS

### Short String

**01ST,GS, 0.0,kg<CR><LF>**

where

|                             |   |
|-----------------------------|---|
| <b>01</b>                   | Code 485 of the instrument (2 characters), only if communication mode 485 is enabled  |
| <b>ST</b>                   | Scale status (2 characters):<br><u>US</u> - Unstable weight<br><u>ST</u> - Stable weight<br><i>NOTE: If parameter ZER.STR is enabled (D-9-5), ZR (Zero status) replaces the ST status when the weight is in zero range (the →0← annunciator displays)</i> |
|                             | <u>OL</u> - Weight overload (out of range)  |
|                             | <u>UL</u> - Weight underload (out of range)   |
|                             | <u>TL</u> - Scale not level (inclinometer active)   |
| ,                           | ASCII 044 character   |
| <b>GS</b>                   | Type of weight data (2 characters)<br><u>GS</u> - Gross<br><u>NT</u> - Net  |
| ,                           | ASCII 044 character   |
| <b>0.0</b>                  | Weight (8 characters including the decimal point)   |
| ,                           | ASCII 044 character   |
| <b>kg</b>                   | Unit of measurement (2 characters)  |
| <b>&lt;CR&gt;&lt;LF&gt;</b> | Transmission terminator, characters ASCII 013 and ASCII 010   |

## Extended String and Extended String 2

**011, ST, 0.0,PT 20.8, 0, 00.00000,kg,-----<CR><LF>**

where

|                             |   |
|-----------------------------|---|
| <b>01</b>                   | Code 485 of the instrument (2 characters), only if communication mode 485 is enabled  |
| <b>1</b>                    | ASCII 049 character   |
| <b>,</b>                    | ASCII 044 character   |
| <b>ST</b>                   | Scale status (2 characters):<br><u>US</u> - Unstable weight<br><u>ST</u> - Stable weight<br><i>NOTE: If parameter ZER.STR is enabled (D-9-5), ZR (Zero status) replaces the ST status when the weight is in zero range (the →0← annunciator displays)</i><br><u>OL</u> - Weight overload (out of range)<br><u>UL</u> - Weight underload (out of range)<br><u>TL</u> - Scale not level (inclinometer active) |
| <b>,</b>                    | ASCII 044 character   |
| <b>0.0</b>                  | Net weight (10 characters including the decimal point)  |
| <b>,</b>                    | ASCII 044 character   |
| <b>PT</b>                   | Indication of pre-set manual tare (2 characters)  |
| <b>20.8</b>                 | Tare weight (10 characters including the decimal point)   |
| <b>,</b>                    | ASCII 044 character   |
| <b>0</b>                    | Number of pieces (10 characters)  |
| <b>,</b>                    | ASCII 044 character   |
| <b>00.00000</b>             | Average piece weight in grams (10 characters including two blank spaces, 2 leading characters, 1 decimal point, and 5 trailing characters)  |
| <b>,</b>                    | ASCII 044 character   |
| <b>kg</b>                   | Unit of measurement (2 characters)  |
| <b>-----</b>                | <b>Only for Extended String 2.</b> Check mode status indicator of OK, OVER, UNDER   |
| <b>&lt;CR&gt;&lt;LF&gt;</b> | Transmission terminator, characters ASCII 013 and ASCII 010   |



## Custom String

Configuration can only be carried out using DiniTools in the “CUSTOM STREAM FORMATTING” section.

The maximum length of the string configuration field is 100 characters. Fixed alphanumeric characters or variable macros may be used inside.

There are also “tokens” that define the characters that a variable (<>) will become in the string when the indicator is in weighing mode.

Create custom strings using the macros on page **130**.

The default custom stream setting is shown below:

**<2><P><W7.><U><M><S><CR><LF>**

where

|                             |   |
|-----------------------------|---|
| <b>&lt;2&gt;</b>            | ASCII STX character (start of text)                         |
| <b>&lt;P&gt;</b>            | Weight polarity   |
| <b>&lt;W7.&gt;</b>          | Weight (formatted to 7 digits with decimal point)           |
| <b>&lt;U&gt;</b>            | Unit of measure   |
| <b>&lt;M&gt;</b>            | Type of weight (gross, net, tare)                           |
| <b>&lt;S&gt;</b>            | Weight status   |
| <b>&lt;CR&gt;&lt;LF&gt;</b> | Transmission terminator, characters ASCII 013 and ASCII 010 |

Default token:

|                               |       |
|-------------------------------|-------|
| Gross mode token “<M>”        | G     |
| Net mode token “<M>”          | N     |
| Tare mode token “<M>”         | T     |
| Preset weight token “<M>”     | T     |
| Unit token “<U>”              | K     |
| Positive polarity token “<P>” | SPACE |
| Negative polarity token “<P>” | -     |
| Invalid status token “<S>”    | I     |
| Motion status token “<S>”     | M     |
| Valid status token “<S>”      | SPACE |
| COZ status token “<S>”        | Z     |
| Overload status token “<S>”   | O     |
| Underload status token “<S>”  | O     |
| Overload char token “<Wn>”    | &     |
| Underload char token “<Wn>”   | =     |

The default command to send to the weight indicator to request the custom string is:

**SF#1<CR><LF>**

## Available Token

| Token           | Format  | Description  | Token value (standard)   |
|-----------------|---|--|--|
| Weight sign     | <p>&lt;P&gt; Sign of the displayed weight</p> <p>&lt;PG&gt; Sign of the gross weight</p> <p>&lt;PN&gt; Sign of the net weight</p> <p>&lt;PT&gt; Sign of the tare</p>  | <p>The string will show the character set in tokens:</p> <p>Positive polarity token "&lt;P&gt;"</p> <p>Negative polarity token "&lt;P&gt;"</p>   | <p>"SPACE" if the weight is positive</p> <p>"-" if the weight is negative</p>  |
| Unit of measure | <U>   | <p>The string will show the character set in token:</p> <p>Unit token "&lt;U&gt;"</p>  | "K", to indicate kg  |
| Weight type     | <p>&lt;M&gt; Displayed weight</p> <p>&lt;MG&gt; Gross weight</p> <p>&lt;MN&gt; Net weight</p> <p>&lt;MT&gt; Tare</p>  | <p>The string will show the character set in tokens:</p> <p>Gross mode token "&lt;M&gt;"</p> <p>Net mode token "&lt;M&gt;"</p> <p>Tare mode token "&lt;M&gt;"</p> <p>Preset tare weight token "&lt;M&gt;"</p>  | <p>"G" if the weight is gross</p> <p>"N" if the weight is net</p> <p>"T" if the weight is a tare</p> <p>"T" if the weight is a preset tare</p>   |
| Weight status   | <p>&lt;S&gt;</p> <p>&lt;Wn&gt;</p>  | <p>The string will show the character set in tokens:</p> <p>Invalid status token "&lt;S&gt;"</p> <p>Motion status token "&lt;S&gt;"</p> <p>Valid status token "&lt;S&gt;"</p> <p>Coz status token "&lt;S&gt;"</p> <p>Overload status token "&lt;S&gt;"</p> <p>Underload status token "&lt;S&gt;"</p> <p>Overload char token "&lt;Wn&gt;"</p> <p>Underload char token "&lt;Wn&gt;"</p>  | <p>"I" if the weight is not valid</p> <p>"M" if the weight is not stable</p> <p>"SPACE" if the weight is valid</p> <p>"Z" if the weight is equal to zero</p> <p>"O" if the weight is in overload</p> <p>"O" if the weight is in underload</p> <p>"&amp;" if the weight is in overload, all the weight digits are replaced by &amp;</p> <p>"=" if the weight is in underload, all the weight digits are replaced by =</p> |
| Weight value    | <p>&lt;W-0x.y&gt; Displayed weight [left align ]</p> <p>&lt;w-0x.y&gt; Displayed weight [ right align]</p> <p>&lt;G-0x.y&gt; Gross weight [left align ]</p> <p>&lt;g-0x.y&gt; Gross weight [ right align]</p> <p>&lt;N-0x.y&gt; Net weight [left align ]</p> <p>&lt;n-0x.y&gt; Net weight [ right align]</p> <p>&lt;T-0x.y&gt; Tare [left align ]</p> <p>&lt;t-0x.y&gt; Tare [ right align]</p> | <p>The string will show the weight. Depending on the parameters set, the format will change accordingly:</p> <p>- Show the sign "-" if the weight is negative</p> <p>0 Fills the empty spaces with "0"</p> <p>X Indicates the number of digits by which the weight is shown (max 15, from 1 to F)</p> <p>. Show the decimal point (If present in the weight)</p> <p>y Indicates the fixed number of digits after the decimal point (If the decimal point is present)</p> <p>- , 0 , . , y characters are optional.</p> |  |
| Bit sequence    | <Bn,Bn,...>   | Indicate a sequence of exactly 8 bits  | See bit table  |
| ASCII character | <X>   |  | <p>Add the ASCII character. "CR" and "LF" are recognised as ASCII character 13 and 10</p> <p>&lt;CR&gt; add the carriage return</p> <p>&lt;LF&gt; add the line feed</p> <p>&lt;2&gt; add the STX character</p>   |

## Bits

| Bit        | Bit used | Type     | Name                           | Description   |
|------------|----------|----------|--------------------------------|---|
| <b>B0</b>  | 1        | Fixed    | Bit value = 0                  | Used to complete the byte   |
| <b>B1</b>  | 1        | Fixed    | Bit value = 1                  | Used to complete the byte   |
| <b>B3</b>  | 1        | Variable | Net weight                     | 1 if the displayed weight is net<br>0 if the displayed weight is gross  |
| <b>B4</b>  | 1        | Variable | Weight equals to zero          | 1 if the gross weight is equal to zero (zero indication on the screen)<br>0 if the gross weight is not equal to zero (no zero indication on the screen) |
| <b>B5</b>  | 1        | Variable | Stable weight                  | 1 if the weight is stable (no motion indication on the screen)<br>0 if the weight is unstable (motion indication on the screen)                         |
| <b>B6</b>  | 1        | Variable | Negative gross weight          | 1 if the gross weight is negative<br>0 if the gross weight is positive  |
| <b>B7</b>  | 1        | Variable | Weight in underload / overload | 1 if the weight is in underload / overload<br>0 if the weight is not in underload / overload  |
| <b>B9</b>  | 1        | Variable | Active tare                    | 1 if a tare is active<br>0 if there isn't a tare active   |
| <b>B10</b> | 1        | Variable | Active preset tare             | 1 if a preset tare is active<br>0 if there isn't a preset tare active   |

Example of custom string configuration to replicate the standard Dini Argeo string:

| <u>String definition</u>       | <S>,<M>,<P><W7>,<U><CR><LF>      |        |
|--------------------------------|----------------------------------|--------|
| Gross mode token "<M>"         | GS                               |        |
| Net mode token "<M>"           | NT                               |        |
| Tare mode token "<M>"          | T                                |        |
| Preset tare weight token "<M>" | PT                               |        |
| Unit token "<U>"               | Depending on the unit of measure |        |
| Positive polarity token "<P>"  | SPACE                            |        |
| Negative polarity token "<P>"  | -                                |        |
| Invalid status token "<S>"     | SPACESPACE                       |        |
| Motion status token "<S>"      | US                               |        |
| Valid status token "<S>"       | ST                               |        |
| COZ status token "<S>"         | ZR                               |        |
| Overload status token "<S>"    | OL                               |        |
| Underload status token "<S>"   | UL                               |        |
| Overload char token "<Wn>"     |                                  | (null) |
| Underload char token "<Wn>"    |                                  | (null) |

Example of custom string configuration to replicate the extended Dini Argeo string:

| <u>String definition</u>       | 1,<S>,<WA.>,<MT><TA.> ,<U><CR><LF> |        |
|--------------------------------|------------------------------------|--------|
| Gross mode token "<M>"         | GS                                 |        |
| Net mode token "<M>"           | NT                                 |        |
| Tare mode token "<M>"          | SPACESPACE                         |        |
| Preset tare weight token "<M>" | PT                                 |        |
| Unit token "<U>"               | Depending on the unit of measure   |        |
| Positive polarity token "<P>"  | SPACE                              |        |
| Negative polarity token "<P>"  | -                                  |        |
| Invalid status token "<S>"     | SPACESPACE                         |        |
| Motion status token "<S>"      | US                                 |        |
| Valid status token "<S>"       | ST                                 |        |
| COZ status token "<S>"         | ZR                                 |        |
| Overload status token "<S>"    | OL                                 |        |
| Underload status token "<S>"   | UL                                 |        |
| Overload char token "<Wn>"     |                                    | (null) |
| Underload char token "<Wn>"    |                                    | (null) |

## 32. COMMUNICATION COMMANDS

in the serial commands and the respective responses

|                   |   |
|-------------------|---|
| <b>nn</b>         | Address 485 of the instrument (2 characters), only if communication mode 485 is enabled |
| <b>&lt;CR&gt;</b> | ASCII terminator character 13 (0D) (1 character)  |
| <b>&lt;LF&gt;</b> | ASCII terminator character 10 (0A) (1 character)  |

### Simple Weight Reading

|                 |                                   |
|-----------------|-----------------------------------|
| <b>Command</b>  | <b>nnREAD&lt;CR&gt;&lt;LF&gt;</b> |
| <b>Response</b> | Short string (see page 127)       |

### Complete Weight Reading

|                 |                                   |
|-----------------|-----------------------------------|
| <b>Command</b>  | <b>nnREXT&lt;CR&gt;&lt;LF&gt;</b> |
| <b>Response</b> | Long string (see page 128)        |

### Reading Custom String

|                 |                                 |                                       |
|-----------------|---------------------------------|---------------------------------------|
| <b>Command</b>  | <b>SF#1&lt;CR&gt;&lt;LF&gt;</b> | <b>(configurable from Dini Tools)</b> |
| <b>Response</b> | Custom string (see page 129)    |                                       |

### Performing a Semi-automatic Tare

|                 |  |
|-----------------|--|
| <b>Command</b>  | <b>nnTARE&lt;CR&gt;&lt;LF&gt;</b>  |
| <b>Response</b> | <b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the command has been received correctly |

### Setting a Tare Value (PT)

|                 |  |
|-----------------|--|
| <b>Command</b>  | <b>nnTMANttttttt&lt;CR&gt;&lt;LF&gt;</b><br>Where t...t is the tare value, with decimal points, max 8 characters.                  |
| <b>Response</b> | <b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the command has been received correctly   |
| <b>Examples</b> | <b>TMAN1.56&lt;CR&gt;&lt;LF&gt;</b><br>sets a tare value of 1.56<br><b>TMAN100&lt;CR&gt;&lt;LF&gt;</b><br>sets a tare value of 100 |

### Clearing the Stored Tare

|                 |  |
|-----------------|--|
| <b>Command</b>  | <b>nnCLEAR&lt;CR&gt;&lt;LF&gt;</b>   |
| <b>Response</b> | <b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the command has been received correctly |

### Zeroing the Scale (ZERO key function)

|                 |  |
|-----------------|--|
| <b>Command</b>  | <b>nnZERO&lt;CR&gt;&lt;LF&gt;</b>  |
| <b>Response</b> | <b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the command has been received correctly |

## SPECIFIC COMMANDS FOR ALIBI MEMORY (OPTIONAL ON DFWX/DFWXB)

### Save Requests

**Command**                    **nnPID<CR><LF>** request to save the weighing

**Response**                    successful registration  
**nnPIDss,c,wwwwwwwwwwuu,ppttttttttuu,xxxx-yyy yy<CR><LF>**

no registration  
**nnPIDss,c,wwwwwwwwwwuu,ppttttttttuu,NO<CR><LF>**

where:

**ss**                            weight status (2 characters)

**TL**                    *t i L t* error condition (NO RECORDING)

**OL**                    *O U E r L o a d* condition (NO RECORDING)

**UL**                    Underload condition (NO REGISTRATION)

**ST**                    Stable weight

**US**                    Unstable weight (NO RECORDING)

**c**                            Scale number (1 character)

**w...w**                    Gross weight (10 characters)

**uu**                            Unit of measurement (2 characters)

**pp**                            Type of tare: double space " " if semi-automatic, "PT" if preset (2 characters)

**t...t**                            Tare value (10 characters)

**xxxx**                            Number of rewrite (5 characters)

**yyyyyy**                            Progressive weighing (6 characters)

**Example**                    PIDST,1, 1500,0kg,PT 2,8kg,00000-000158<CR><LF>

### Reading a Stored Weighing

**Command**                    **nnALRDxxxx-yyy yy<CR><LF>**  
 Where xxxx is the rewrite number, yyyy is the weighing sequence.

**Response**                    **s , w w w w w w w w w u u , p p t t t t t t t t t u u<CR><LF>**

where:

**s**                            Number of scales (always 1)

**w...w**                    Gross weight (10 characters)

**uu**                            Unit of measurement ("g", "kg", "t", "lb")

**pp**                            Type of tare: double space " " if semi-automatic, "PT" if preset (2 characters)

**t...t**                            Tare value (10 characters)

**Example**                    ALRD00000-000158<CR><LF>  
 1, 1500,0kg, 2,8kg<CR><LF>

### 33. PROGRAMMING ERRORS

| MESSAGE         | DESCRIPTION                                      | SOLUTION   |
|-----------------|--|--|
| <i>AL.Err</i>   | "Alibi memory" board (optional) not detected     | Check the presence of the board inside the indicator. If present, check it is not damaged and is installed correctly.  |
| <i>Er.1.b.H</i> | "inputs / outputs" board (optional) not detected | Check the presence of the board inside the indicator.<br>If missing, deactivate any inputs or outputs (parameter " <i>inPuT5</i> " or " <i>ouTpuT</i> ", see page <b>107-108</b> ).<br>If present, check it is not damaged and is installed correctly. |
| <i>Er.r.b.H</i> |  |  |
| <i>E9.Err</i>   | Impossible to perform equalisation               | Check the cells are connected properly.<br>Check the signal of each cell in the diagnostic menu (menu <i>d.iAG</i> , parameter <i>AdC.uU</i> , see page <b>110</b> ).  |
| <i>PrEC.</i>    | Calibration error                                | First calibrate the zero point, then proceed with the next points.   |
| <i>Err.Pnt</i>  | Calibration error                                | Check the connection of the load cell.<br>Check that the cell signal is stable, valid and greater than that of the previously acquired point.  |
| <i>Er 11</i>    | Calibration error                                | Increase the calibration weight.   |
| <i>Er 12</i>    | Calibration error                                | Check that the signal coming from the cell increases upon the increasing of the weight loaded on the scale. When acquiring the calibration points, use the increasing calibration weights.   |
| <i>Er 37</i>    | Calibration error                                | Repeat the calibration, checking that the capacity and division have been correctly set.   |
| <i>Er 39</i>    | Instrument not configured                        | Reset the factory configurations (menu <i>AdUAnC</i> , parameter <i>dFLt.t</i> , see page <b>123</b> ).  |
| <i>Er 85</i>    | Instrument configured but not calibrated         | Perform calibration.   |
| <i>Er. 36</i>   | Calibration error                                | Check that the signal coming from the load cell is not negative.   |
| <i>Err.Not</i>  | Unstable weight                                  | Check in the menu <i>d.iAG</i> , parameter <i>AdC.uU</i> (see page <b>110</b> ) that the signal is stable and try again.<br>If the connection of the cells is with 4 wires, check that the sense jumpers are inserted.                                 |

## 34. FAQ - FREQUENTLY ASKED QUESTIONS

### Calibration

#### Can I change the maximum capacity without recalibrating?

Yes, change the `rRNGE 1.2.3` parameters (**Q-1-5**, **Q-1-6**, **Q-1-7**) (see page **113**).

#### Can I change the division without recalibrating?

Yes, change the `d d` parameter (**Q-1-4**). (See page **113**)

#### Can I change the position of the decimal point without recalibrating?

Yes, change the `dEC d` parameter (**Q-1-1**) and the value of the calibration points (**Q-1-3**) (see page **112** and **113**).

#### Can I calibrate the instrument in “multi-division” mode?

Yes, using the advanced configuration function from PC and the Dinitools program.

### Communication

#### Scale does not communicate

- Check that the cable is in good condition and that there are no faults (use a multimeter).
- Check that the communication port of the PC or device being used is not compromised. If necessary, try another device / PC.
- Check that you have connected the cable to the correct serial port.
- Check step configuration `bRud` and `b t5` (See page **59-81**).
- Temporarily activate continuous communication and retry string reception. If the string has been received correctly, carefully check the syntax of the command sent, the communication timeouts and the presence of the terminator.

### Generic

---

#### The scale does not turn on

- Check that the input voltage level to the motherboard is correct.
- Try forced power by inserting the “ON BOOT” jumper present on the motherboard. If the indicator lights up, check the correct operation of the keypad, using the diagnostics menu `d d` (See page **111**).
- Possible failure of the internal rechargeable battery (if present).



## 35. BATTERY REMOVAL

This section discusses how to remove and replace batteries found in DFWX series indicators. Depending on options, DFWX indicators can contain up to two batteries:

- 3V CR2032 battery on optional ALIBI module.
- 3.7V LiPo battery is standard in DFWXB, DFWXXB-HGX, DFWXB-WiFi and DFWXB-WIF-HGX models



### Battery Disposal:

Dispose of batteries at appropriate waste collection centers at the end of their life cycle in accordance with local laws and regulations. Batteries and rechargeable batteries may contain harmful substances that should not be disposed of in household waste. Batteries may contain harmful substances including but not limited to: cadmium (Cd), lithium (Li), mercury (Hg) or lead (Pb). Users who dispose of batteries illegally shall face administrative sanctions as provided by law.

**WARNING: Risk of fire and explosion. Do not burn, crush, disassemble or short-circuit batteries.**

**Important: All included batteries included intended for sale in the EU market are classified as "Portable Batteries for General Use" and comply with European Battery Regulation (EU) 2023/1542.**


---

## Alibi Battery Removal/Replacement

---

Required Parts and tools:

- 7 mm wrench to remove nuts and open cover.
- Antistatic work surface
- Anti-static wrist strap
- Short and thin non-conductive tool (such as a thin wood dowel)
- New CR2032 3 V battery



7 mm



**IMPORTANT:** The CR2032 must be installed in the correct polarity ,otherwise damage could occur. The battery bracket indicates the orientation of the positive polarity.



**IMPORTANT:** Use anti-static protection for grounding and to protect components from electrostatic discharge (ESD) when working inside the enclosure or removing parts from the enclosure.



**WARNING:** Dispose of battery according to local laws and regulations.




**WARNING:** Removing the CR2032 battery causes all Alibi data to be lost.

1. Turn off the indicator.
2. Disconnect the indicator power cable from the power outlet.
3. Place instrument on an anti-static surface.
4. Use a 7 mm wrench to remove retaining nuts on instrument's back panel.
5. Set back panel aside.





**CAUTION:** Handle the back panel carefully as it is attached to the indicator's ground circuit.




**CAUTION:** A ground wire is attached to the back panel, detach ground retaining nut and wire with 5.5 mm wrench if needed.


6. Locate the ALIBI module (installed directly on the CPU board or on the digital input and output card card).



2. Observe the two battery access slots on the rear of the battery bracket.
3. Carefully push the battery from the rear access slots with non-conductive tool until it slides out of the battery bracket.
4. Insert a new battery with negative side toward PCB and positive side toward back cover.
5. Reinstall cover using retaining nuts and 7 mm wrench.
6. Reconnect power cord to power outlet and resume operation.



7. For systems with Alibi, reset the Alibi memory after the battery is changed.



---

## Battery Removal/Replacement


---

Required tools:

- Spare battery (if replacing)
- 5.5 mm and 7 mm Nut drivers

**NOTE:** 5mm driver removes nuts inside the enclosure while 7 mm driver removes nuts on the outside of cover.

- Phillips 0 screwdriver (to remove screws inside the enclosure)
- Anti-static work surface
- Anti-static wrist strap



**PH0    7 mm**



**IMPORTANT:** The battery must be installed in the correct polarity otherwise damage could occur.



**IMPORTANT:** Use anti-static protection for grounding and to protect components from electrostatic discharge (ESD) when working inside the enclosure or removing parts from the enclosure.



**WARNING:** Dispose of battery to according local laws and regulations.



**WARNING:** When replacing the battery, use original batteries supplied by Dini Argeo.


### Battery Removal Procedure

1. Turn off the indicator.
2. Disconnect the instrument's power cable from the power outlet.
3. Place instrument on an anti-static surface.


2. Remove back panel retaining nuts with a 7 mm wrench.



**CAUTION:** A ground wire is attached to the back panel, detach ground retaining nut and wire with 5.5 mm wrench if needed.




3. Disconnect the battery cable from battery charging board on J2 (see wiring diagram on page 20).




5. Remove the Phillips screw retaining the battery mounting bracket.


**NOTE:** This mounting screw also holds the power supply in place on one side. Ensure to reattach the mounting screw if the battery is not replaced.



6. Detach the hex standoff retaining the battery mounting bracket.



7. Carefully remove the battery and bracket from the enclosure.



**WARNING: Risk of fire and explosion. Do not burn, crush, disassemble or short-circuit batteries.**

Battery replacement:

1. Reverse the previous procedure, ensuring the battery power cable faces up.
2. When complete, plug charging cable in J2 in the battery charging board.

## NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

This publication, or portions thereof, may not be duplicated without written permission from the Manufacturer. All information contained in this manual is based on the data available at the time of its publication; the Manufacturer reserves the right to make changes to its products at any time without notice and without incurring any penalty. We therefore recommend that you always check for any updates.

The individual in charge of the scale operation must ensure that all safety regulations in force in the country of use are applied, ensuring that the appliance is used in accordance with the purpose it is intended for and to avoid any danger for the user.

The Manufacturer declines any liability arising from any weighing operation errors.











A RICE LAKE WEIGHING SYSTEMS COMPANY

**HEAD OFFICE**

Via Della Fisica, 20  
41042 Spezzano di Fiorano, Modena - Italy  
Tel. +39 0536 843418 - Fax +39 0536 843521

**SERVICE ASSISTANCE**

Via Dell'Elettronica, 15  
41042 Spezzano di Fiorano, Modena - Italy  
Tel. +39 0536 921784 - Fax +39 0536 926654

[www.diniargeo.com](http://www.diniargeo.com)

Stamp of the authorised service centre

