



Service Manual

	Contents	1
Ι.	Assembly drawing	2
1 – 1	Explosive view (JWL)	2
1 – 2	List of parts (JWL)	3
1 – 3	Block diagram of electronic structure	4
1 – 4	Wiring diagram	5
2.	Troubleshooting procedure	6
2 – 1	Troubleshooting flow	6
2 – 2	Troubleshooting table	7
2-3	Confirmation of application environment	7
2 – 4	Simple inspection of electric circuit	8
2 – 5	Performance inspection	8
3.	Maintenance and setting	9
3 – 1	Maintenance flow	9
3 – 2	Model setting	9
4.	Setting of parameters	10
4 – 1	Parameter setting	10
4 – 2	Description of parameter values	11
4 – 3	Unit setting	13
5.	Linear calibration	17
6.	Single point calibration	19
7.	Error message list	21
8.	External interface	22
8 – 1	RTC function setting	22
8 – 2	Signal output pins of three-in-one board	24
8 – 3	Single option	24
8 – 4	Two options	34
8 – 5	RS232 output format	36
9.	Others	38
10.	Circuit diagram	41
10 – 1	CPU, peripheral and other circuits	41
10 – 2	LCD circuit	42
10 – 3	Applicable mainboard version and software version	42

1. Assembly Drawing

1 – 1 Explosive view



1-2 List of parts

No.	Name	Quantity	Part No.	Material No.
1	xm JWL-Chinese	1	JWL-1	21-1925-0100
	front panel			
2	xm key	1	JWL-2	21-0506-0100
3	xm level meter	1	JWL-3	02-0108-0003xm(14mm)
4	Xm transformer	1	JPL-4	61-0003-0400
5	Xm switch	1	JWL-5	60-0000-0000xm
6	Xm power socket	1	JWL-6	80-0125-0000
7	xm semi-finished	1	JPL-7	60-0503-0001xm
	JWL board			
8	Xm lower cover	1	JWL-8	02-0000-6020
9	xm lower support	1	JWL-9	10-0425-0100
10	Xm screw for	1	JPL-10	31-0404-0000xm
	transport protection			
11	Xm rubber levelers	4	JWL-11	01-0100-0030
12	xm RS232 board	1	JCL-12	80-0900-2200xm
13-1	xm sensor - Chung	1	JWL-13	51-0400-0400xm
	Yuen 3k			
13-2	xm sensor - Chung	1	JWL-13	51-0410-0000
	Yuen 5k			
13-3	xm sensor- Chung	1	JWL-13	51-0410-0010
	Yuen 10k			
13-4	xm sensor - Chung	1	JWL-13	51-0410-0020
	Yuen 20k			
13-5	xm sensor - Chung	1	JWL-13	51-0410-0040
	Yuen 40k			
14	Xm storage cell	1	JWL-14	61-0201-0098xm
15	Xm cell cover	1	JWL-15	02-0000-6030
16	Xm rear PCB	1	JPL-16	80-0126-0010
17	xm upper support	1	JWL-17	10-0425-0000
18	xm upper cover	1	JWL-18	02-0000-6010
19	xm rear panel	1	JWL-19	20-0000-6040
20	xm plastic	1	JCL-20	02-0000-6040
	down-warped pan			
21	xm stainless steel	1	JCL-21	12-0000-1200
	down-warped pan			

1 – 3 Block diagram of electronic structure



JWL SYSTEM BLOCK

1 – 4 Wiring diagram(圖中中文應去除)



2. Troubleshooting Procedure 2- 1 Troubleshooting flow



2–2 Troubleshooting table

Error message	Causes
LCD,	1. Cell or transformer fault
backlight board	2. Power switch fault
or	3. Power circuit fault
buzzer	4. LCD or related LCD circuit fault
does not work	5. Backlight board or backlight related circuit fault
	6. Buzzer fault or buzzer circuit fault
	7. CPU or oscillating circuit fault
AC current or	1. Power socket fault
cell can't be	2. Transformer fault
used.	3. Cell fault
	4. Power circuit fault
	5. Main board fault
Err5	1. Overload (max weighing +9e)
	2. Too high or inaccurate calibrated COUNT value.
Cell sign	1. Insufficient cell voltage or cell failure
	2. Main board fault
Instable	1. The pan is interfered by any article.
indication	2. There is strong wind or vibration nearby.
	3. The cell voltage is insufficient.
	4. There is external electromagnetic interference.
Bad linearity	1. The pan is interfered by any article.
	2. Bad L/C

2-3 Confirmation of the application environment

- a. Is there a strong wind in the workplace?
- b. Is there vibration or instability in the workplace?
- c. Is there any article on the pan?
- d. Is the stainless steel pan placed on the tray?
- e. Has the screw for transport protection been removed?
- f. Is the scale set on a horizontal plane?

2 –4 Simple inspection of electric circuit

a. Check if the power supply is normal

- 1. Is the voltage 5V at both E+ and E- terminals? Check whether the CPU supply is normal.
- b. Check the signal input

1. Check if the outputs from S+ and S- terminals to G change in accordance with the weight on the pan.

- c. Check the digital signals
 - (1) Check if there is oscillation in Y1's output pin.
 - (2) Check if there is oscillation in Y2's output pin.

2 – 5 Performance Inspection

a. Repetitiveness

Put the weight of two thirds of the load on the pan for five times, the indication difference between different times should be less than or equal to one division value.

b. Unbalanced loading error

Put the weight of one third of the load on the pan (as shown in the figure). Check if the figure is precise. The indication difference between the four corners should be less than or equal to one division value.



c. Linearity

Load conditions	Permissible error
Idle ~ one third of the load	0 e
One third of the load ~ two thirds of the load	1 e
Two thirds of the load ~ full load	2 e

3. Maintenance and Setting 3 – 1 Maintenance flow



3 –2 Model setting

Model setting: Press **MR** to turn on the unit (the LCD will display 3.0000) and then press **UNIT** to select the unit model (for example:1.50000, 3.0000, 6.0000, 7.5000, 15.0000, 30.000). Press **G/N** and the unit will display "dlu-01" and enter accuracy selection. Press **UNIT** to select from diu-01 (1/30000), diu-02 (1/15000), diu-03(1/6000), diu-04 (1/3000), etc. and then press **G/N** to store the setting and return to the weighing mode.

4. Setting of Parameters

4-1 Parameter setting



4-2 Description of parameter values

Item	Function	Display	Description		
	Automatic turn-off will be executed when the weight is smaller	s off	No setting		
		5	5 min		
DOO		Ш	10 min		
P00		30	30 min		
	than 9 divisions.	60	60 min		
		<i>90</i>	90 min		
P01	Buzzer beep	iΠ	There will be an acoustic warning when the weight of the material is between the preset upper and lower limits (including the upper and lower limits).		
		ollt	There will be an acoustic warning when the weight of the material is beyond the preset upper and lower limits and the weight is more than 20 divisions.		
		Lo_U	There will be an acoustic warning when the weight of the material is less than the preset lower limit and the weight is more than 20 divisions.		
		☆ <i>Ш</i> ?	There will be an acoustic warning when the weight of the material exceeds the preset upper limit.		
		☆ <i>PE</i>	PC output		
	Printer selection	58-24	Dot-matrix		
P02		LodEh	Automatic sticking, paper size: 5cm*3cm		
		7EbrR	Automatic sticking, paper size: 5cm*3cm		
		685456	Automatic sticking, paper size: 5cm*3cm		
Dee	RS-232	24	The transmission rate is 2400		
P03	transmission rate	48	The transmission rate is 4800		

		☆	96	The transmission rate is 9600
P04	Turn-on or off of the weight check memory		Υ£ς	Automatic turn-on of the check mode when the unit is turned on next time.
		☆	No	No automatic turn-on of the check mode when the unit is turned on next time.
P05	Parity check	☆	nonE	No parity.
			የጸራ ሊያ	The parity can be odd or even.
			۵n	Backlight display will be on for the whole process
P06	Backlight selection		oFF	No backlight display
	Dacklight Selection	☆	anoFF	Backlight display will be on when the weight is greater than 9 divisions.
P07	Printing mode selection		<i>Ρ</i>	Manual printing
		☆	5£	Stable printing (the next printing will be made only when the indication is returned to zero.)
			[o	Continuous printing
	Filter grade selection	☆	1	Worst vibration resistance
P08			2	Average vibration resistance
			}	Good vibration resistance
			Y	Best vibration resistance
P09	Zero indication range	☆	7Ero-0	No restriction on the zero indication

	PEro-l	At a zero indication, only when at least 2 divisions or above is put on the pan will a value be indicated.
--	--------	---

		7Ero-2	At a zero indication, only when at least 3 divisions or above is put on the pan will a value be indicated.
		7Ero-3	At a zero indication, only when at least 4 divisions or above is put on the pan will a value be indicated.
		7Ero-4	At a zero indication, only when at least 5 divisions or above is put on the pan will a value be indicated.
		7Ero-5	At a zero indication, only when at least 6 divisions or above is put on the pan will a value be indicated.
P10	Factory initialized setting	in it -F	It is a factory set value.
P11	Unit setting	SEEU	The specific operation is as follows:

4-3 Unit setting









5. Linear Calibration

\bigstar If the linear calibration is made, there is no need to make the single point calibration. If the sensor has a good linearity, make the single point calibration directly.



	(4). Wait till ON 2 flickers on the LCD and put on the weight 2/3 of the full load. For example, 2/3 of the weighing 30kg is 20kg.
	(5). Wait till ON 3 flickers on the LCD and put on the weight of the full load.
 	(6). Wait till PASS appears. Now, take away the load from the pan.
	(7).Press TARE to return to the weighing mode.

6. Single Point Calibration(底下少圖)







7. Error Message List

Error message	Possible causes	Solutions
E02 no.samp	No PCS sampling	Press G/N to make the sampling.
E04 EE.ERR	EEPROM reading error	Re-weld the EEPROM or contact the service department.
E05 out.ran	Overload (max weighing+9 divisions)	Take away the overload.
E07 E.Lo>Hi	The upper limit set for the weight check is lower than the lower limit.	Press FRINT to correct the setting of HI/LO.
E08 CK.UNIT	The unit set for the weight check is not the same as the current unit.	Close the weight check or re-set the value of HI /LO.
EU.nit	Interference between the accumulation units	Return to the last accumulation unit or re-do the accumulation.

8. External Interface

- ☆If an external interface is needed, please select a three-in-one board, which combines RTC (time display) ,RS-232 and Relay (weight check) on one circuit board. Only by selecting this board can the three functions be realized.
- ☆ After a three-in-one board is selected, a setting should be made on the scale for time display if necessary.

8-1. RTC function setting





8-2 Signal output pins of three-in-one board





8-3 Single option

8-3-1 Printer output

■Parameter setting





Wire connecting the scale and the printer





8-3-2 PC output

Parameter setting



select the parameter value, with the printing modes including 52/92/Co.
(3). Follow Step (2) to select the parameter item P02, with the printing mode selected as PC.
(4). Follow Step (2) to select the parameter item P03, selecting the Baud rate from 2400/4600/2600.



■Wire connecting the scale and the PC

How to use a PC to receive the weighing information?

- (1) Use the connecting wire as shown in the following figure to connect the scale and the PC.
- (2) Set the printing mode as continuous.
- (3) Now, the scale will output the data to the PC.

(Of course, you must have a receiving program at the PC end.)



8-3-3 Warning light connection for use







Setting for the upper and lower limits of weight check



Note: After	completing	Step (4),	you	may
directly pres		to store	the up	oper
limit value o	r directly ski	p to Step	(6).	



Note: 2-1. When the material weight exceeds 10.000kg, there will be an acoustic warning and the red light will be on.

2. When the material weight is smaller than or equal to 10.000kg and greater than or equal to 1.000kg, the green warning light will be on.

3. When the material weight is smaller than 1.000kg and greater than or equal to 20 divisions, the orange warning light will be on.

acoustic warning and the red light will be on.

2. When the material weight is smaller than or equal to 10.000kg and greater than or equal to 1.000kg, the green warning light will be on.

3. When the material weight is smaller than 1.000kg and greater than or equal to 20 divisions, there will be an acoustic warning and the orange warning light will be on.

n-1. When the material weight exceeds 10.000kg, the red light will be on.

2. When the material weight is smaller than or equal to 10.000kg and greater than or equal to 1.000kg, there will be an acoustic warning and the green warning light will be on.

3. When the material weight is smaller than 1.000kg and greater than or equal to 20 divisions, the orange warning light will be on.

 La^{U}_{-1} -1. When the material weight exceeds 10.000kg, the red light will be on.

2. When the material weight is smaller than or equal to 10.000kg and greater than or equal to 1.000kg, the green warning light will be on.

3. When the material weight is smaller than 1.000kg and greater than or equal to 20 divisions, there will be an acoustic warning and the orange warning light will be on.

Pins for connecting the warning lights

Pins for connecting the warning lights	Picture



Wire connecting the scale and the warning light



8-4. Two options

8-4-1 Joint use of PC output and warning light

8.4.1.1 The parameter setting is the same as specified in 8-3-2, 8-3-3 8.4.1.2 Wire connecting the scale to the PC and the warning light



8-4-2 Joint use of SH-24 printer output and warning light

8-4-2-1 The parameter setting is the same as specified in 8-3-1 and 8-3-3 8-4-2-2 Wire connecting the scale to the SH-24 printer and the warning light

Wire connecting the	Picture	
SH-24 printer and the		
warning light		



8-4-3 Joint use of ZEBRA or other printers and warning light

8-4-3-1 The parameter setting is the same as specified in 8-3-1 and 8-3-3 8-4-3-2 Wire connecting the scale to a ZEBRA or other printers and the warning



8-5. RS-232 output format Baud Rate: 2400, 4800, 9600 Data Bit: 8

Parity: N (None) Stop Bit: 1 Code: ASCII

Bit Format:



Data Format:

Bulu		mat.										
g												
Ν	•	w		:	+/-					g	CR	LF
Т	•	w	-	:	+/-					g	CR	LF
G	•	w		:	+/-					g	CR	LF
							Weight					

Example N.W.: + 1000.0 g T.W.: + 500.4 g G.W.: + 1500.4 g

kg													
Ν	•	w	-	:	+/-					k	g	CR	LF
т	-	w	-	:	+/-					k	g	CR	LF
G		w	-	:	+/-					k	g	CR	LF
						١	Neight						

Example

N.W.: + 1.0000 kg T.W.: + 0.4998 kg G.W.: + 1.4998 kg

lb

Ν	W	:	+/-					Ι	b	CR	LF
т	w	:	+/-					Ι	b	CR	LF
G	W	:	+/-					Ι	b	CR	LF

Weight

Example

N.W.: + 2.2050 lb T.W.: + 1.1020 lb G.W.: + 3.3070 lb

Jin (Taiwan)

N	-	w	-	:	+/-					G	-	t	I	Т	CR	LF
т	•	w		:	+/-					G	-	t	I	т	CR	LF

G	w	:	+/-						G	-	t	I	•	т	CR	LF
					We	ight										

Example

N.W.: + 1.94.8 G-tl.T T.W.: + 0.13.2 G-tl.T G.W.: + 2.08.0 G-tl.T

Jin (Hong Kong)

	•		_		_															
Ν		w	•	:		+/-							G	-	t	Ι	•	н	CR	LF
т		w		:		+/-							G	-	t	Ι		н	CR	LF
G		w	•	:		+/-							G	-	t	I		н	CR	LF
									1	Neig	ht									

Example

N.W.: + 1.94.4 G-tl.H T.W.: + 0.13.2 G-tl.H G.W.: + 2.07.6 G-tl.H

PCS

t	0	t	а	-	:										CR	LF
												р	с	s	CR	LF

Example

Total: 50pcs

9. Others

9-1 Options

Example of use of single option

	Option		External device		Output format
AP0	RS232+RTC+Relay	+	PC		2008/06/16 10:25:54 N.W.: + 52 g T.W.: + 0 g G.W.: + 52 g
AP1	RS232+RTC+Relay	+	BP-545D		2008/06/26 14:58:48 N.W.: + 3.662 kg T.W.: + 0.000 kg G.W.: + 3.662 kg
AP2	RS232+RTC+Relay	+	SH-24	→	2008/06/16 10:25:54 N.W.: + 52 9 T.W.: + 0 9 G.W.: + 52 9
AP3	RS232+RTC+Relay	÷			2000/00/00 00:00:00 N.W.: + 3.658 kg T.W.: + 0.000 kg G.W.: + 3.658 kg

|--|

AP4	RS232+RTC+Relay	+	LED Light Tower	→	Applicable to the quality control of the factory product quantity or weight and that of the total production line.
AP5	RS232+RTC+Relay	÷			2008/06/26 17:27:45 N.W.: + 3.661 kg T.W.: + 0.000 kg G.W.: + 3.661 kg
			GODEX(EZ)		

• Examples of use of options



10-1. CPU, peripheral circuit and other circuits



10-2. LCD circuit



10 - 3. Applicable mainboard version and software version

Mainboard version: JWL-V1.1 (50-0900-0000) Software version: JWL1.01 Revision date: Nov. 28, 2008