

DINITOOLS DRIVER UPDATE


NOTE

- The following procedure will explain how to update the Dinitools Driver, in order to correctly manage the Setup of the supported indicators.

- 1) Extract the driver from the zip file.
- 2) Launch the file, the following window will appear:



- 3) The driver suggests the default path of the “Setups” folder, in the Dinitools directory: **if the actual path is different, press on the “...” button:**





Select the the correct path and press “OK”.

4) The new path has been set; press on “EXTRACT” to proceed with the installation:





5) Press "OK".

6) From the 3.04.00 Dinitools version, on the bottom right of the main window it is possible to see the version of the driver installed:

