

JCL – Counting function

Start the scale. Put on a bowl if you have one and press TARE.

Then add 10-20 pieces of what you count.

Type the keypad number how many you have put in the bowl and press SMPL. Then put the rest in the bowl, now it show how many it's total.

To zero when you want to count something else, press 0, then the UWS / ITEM button, then everything will be zero in the display.

Then repeat the above procedure for everything that should be counted.

NOTE! To be able to count small objects, you need to add more than just 10 pcs, preferably 30-50 pcs for the scale to show a correct result.