



Sauter GmbH

Ziegelei 1
D-72336 Balingen
E-Mail: info@sauter.eu

Tel: +49-[0]7433- 9933-199
Fax: +49-[0]7433-9933-149
Internet: www.sauter.eu

Akku anschließen / Mounting Battery

	Zur Inbetriebnahme des UCI-Härteprüfgerät HO bitte den Akku anschließen.		
	Beigelegten Inbusschlüssel aus der Box nehmen.		Kabel einstecken und auf festen Sitz prüfen.
	Zum öffnen des Akkufachs die Schraube öffnen.		Akku einlegen und das Kabel so verstauen, dass ein Einklemmen durch den Deckel vermieden wird.
	Deckel abnehmen und Akku herausnehmen.		Deckel schließen und die Befestigungsschraube anziehen
	Hier muss der weiße Stecker des Akkus eingesteckt werden. Auf richtige Polung achten.		Gerät einschalten, um die Funktion zu testen und den Akku aufladen.












Sauter GmbH

Ziegelei 1
D-72336 Balingen
E-Mail: info@sauter.eu

Tel: +49-[0]7433- 9933-199
Fax: +49-[0]7433-9933-149
Internet: www.sauter.eu

Akku anschließen / Mounting Battery

	To start up the UCI hardness tester HO please connect the battery.		
	Use Allen key out of the box.		Plug in the cable and check for tightness.
	To open the battery compartment open the screw.		Inserting the battery and store the cable that jamming is prevented by the cover.
	Remove the lid and take out the battery.		Close the lid and tighten the fixing screw.
	Insert here the white connector of the battery. Check the correct polarity.		Switch on the device to test the function and charge the battery.