

TW

TW SERIES OVERHEAD MONORAIL WEIGHING SCALES



Low profile weighing modules for overhead monorails, easily adaptable with any type of monorail track systems, even already existing ones. Fitted approved load cells.

Working in cooperation with:

Vetek AB

Hantverkarsvägen 15 - 76493 - Vaddö, Sweden
Tel. +46176208920 info@vetek.com

The best solution
for advanced industrial
applications

MAIN FEATURES

- Functions with 1 aluminium load cell with IP66 protection degree (TWSI model) or with 3 STAINLESS STEEL load cells with IP68 protection degree (TWI model), approved according to OIMLR60 C3 standards (3000 + 3000 divisions).
- AISI304 STAINLESS STEEL tubular structure, fitted with accessories for fastening to the beam and threaded rods for fastening to the customer's track section.
- Maximum length of the customer's track section:
 - 300 mm for the ETWSI models
 - 600 mm for the ETWI models.
- Up to 15 Vdc power supply.
- Hermetic junction box and shielded 10m long 6-pin cable fitted with connectors for connection to the weight indicator.

OPTIONS ONLY AVAILABLE AT TIME OF ORDER

- Connection to the indicator and calibration with CE-M 3000e single range or 3000e+3000e dual range approval (with our indicators).
- Models with special sizes and capacities (ask for estimate).
- Possible adaptations with customer's track section (to be supplied per account of manufacture), which will be quantified upon job card cost account.

VERSIONS

Versioni disponibili

Codice	N° celle	Max (kg)	d (g)	 (g) *	 2R (g) *
TWSI15 	1x300kg	150	50	50	20-50
TWSI30 	1x500kg	300	100	100	50-100
TWI30 	3x300kg	300	100	100	-
TWI60 	3x500kg	600	200	200	100-200

(*) Divisioni CE-M ottenibili solo con le relative opzioni.

NOTE:



- Il tratto di guidovia da applicare alla bilancia e i necessari fissaggi alle barre filettate devono essere realizzati dal cliente.
- L'ordine e l'eventuale adattamento della bilancia sono possibili previa verifica della compatibilità col tratto di guidovia del cliente (eseguita dai nostri tecnici all'invio dell'apposito [MODULO COMPILATO](#)).



www.diniargeo.com



DINI AR GEO
FRANCE sarl
Nogent-sur-Marne

DINI AR GEO
GMBH
Sinsheim - Germany

DINI AR GEO
UK Ltd
Taunton - United Kingdom

DINI AR GEO WEIGHING
INSTRUMENTS Ltd
Shanghai - China

DINI AR GEO
WEIGHBRIDGES
Calto (RO) - Italy



HEAD OFFICE
Via Della Fisica, 20
41042 Spezzano di Fiorano Modena - Italy



Vetek AB

Hantverksvägen 15 - 76493- Vaddö

Tel. +46176208920 info@vetek.com

SALES AND TECHNICAL ASSISTANCE SERVICE