



Electronic STAINLESS STEEL weighing low profile platforms with removable loading plate fitted with IP68 STAINLESS STEEL C6 approved load cells. Suitable for creating scales and electronic weighing systems for all types of industrial and commercial applications. Available in high resolution and suitable for ATEX zones.

Working in cooperation with:

Vetek AB

Hantverksvägen 15 - 76493 - Väddö - SWEDEN
Tel. 0046-176208920 Fax. 0046-176208929
patrik@vetek.com

**The best solution
for advanced industrial
applications**

MAIN FEATURES

- Fitted with 4 STAINLESS STEEL shear-beam C6 load cells each with 350 Ohm input resistance. OIML R60 approved and protection against dust and immersion according to IP68 standards.
- Stainless steel bearing tubular structure, with removable stainless steel plate and IP67 junction box housing.
- Adjustable, stainless steel shock-proof jointed feet and integrated level.
- Shielded 5m long 6-pin cable for connection to a weight indicator.
- Fitted with IP68 connector.
- Up to 15 Vdc power supply.

OPTIONS ONLY AVAILABLE AT TIME OF ORDER

- Calibration with CE-M single or double range approval.
- High resolution models for internal factory use.
- AVAILABLE ON REQUEST: reinforced version for weighing of concentrated loads (coils, forklifts ecc.)

ACCESSORIES

- Column support for weight indicator.
- Frames for flush floor installation.
- Access ramps.
- Models with special sizes and capacities on request.

OPTIONS FOR ATEX VERSION

- CCATEX: ATEX certificate for each load cell.
- JB4QA: ATEX certified junction box.
- DCATEXMECH: ATEX declaration for the PLATFORM (for the load cells ATEX declaration see CCATEX-1 code). Option to be offered only if the platform is ordered without the indicator, if so, refer to the chosen weight indicator available certifications.

DETAIL 1



DETAIL 2



VERSIONS

Available versions

Codice	I x w x h (mm)	N° celle	Max (kg)	d (g)	M (g)*	M 2R (g)*	d HR (g)*
ETAI3C6	1000x1000x90	4x220kg	300	50	50	--	20
ETAI6C6	1000x1000x90	4x500kg	600	100	100	--	50
<u>ETAI15C6</u>	1000x1000x90	4x500kg	1200	200	200	100-200	100
<u>ETMI3C6</u>	1000x1250x90	4x220kg	300	50	50	--	20
<u>ETMI6C6</u>	1000x1250x90	4x500kg	600	100	100	--	50
<u>ETMI15C6</u>	1000x1250x90	4x500kg	1200	200	200	100-200	100
ETBI3C6	1250x1250x90	4x220kg	300	50	100	--	20
ETBI6C6	1250x1250x90	4x500kg	600	100	100	--	50
ETBI15C6	1250x1250x90	4x500kg	1200	200	200	100-200	100
ETBI30C6	1250x1250x90	4x2000kg	3000	500	500	--	200
ETDI6C6	1250x1500x115	4x500kg	600	100	100	--	50
ETDI15C6	1250x1500x115	4x500kg	1200	200	200	100-200	100
ETDI30C6	1250x1500x115	4x2000kg	3000	500	500	--	200
ETEI6C6	1500x1500x115	4x500kg	600	100	100	--	50
ETEI15C6	1500x1500x115	4x500kg	1200	200	200	100-200	100
ETEI30C6	1500x1500x115	4x2000kg	3000	500	500	--	200
ETFI6C6	1500x2000x130	4x500kg	600	100	100	--	50
ETFI15C6	1500x2000x130	4x500kg	1200	200	200	100-200	100
ETFI30C6	1500x2000x130	4x2000kg	3000	500	500	--	200

(*) Divisions obtainable only with the relative options, in combination with Dini Argeo weight indicator.



www.diniargeo.com



“YOUR WORLDWIDE PARTNER FOR WEIGHING,”

DINI ARGEO
FRANCE sarl
Nogent-sur-Marne

DINI ARGEO
GMBH
Sinsheim - Germany

DINI ARGEO
UK Ltd
Taunton - United Kingdom

DINI ARGEO WEIGHING
INSTRUMENTS Ltd
Shanghai - China

DINI ARGEO
WEIGHBRIDGES
Calto (RO) – Italy



HEAD OFFICE
Via Della Fisica, 20
41042 Spezzano di Fiorano Modena - Italy



Vetek AB

Hantverksvägen 15 - 76493 - Väddö - SWEDEN

Tel. 0046-176208920 Fax. 0046-176208929

patrik@vetek.com

SALES AND TECHNICAL ASSISTANCE SERVICE