

TPWNBT

TPWNBT "BATTERY" PALLET TRUCK SCALE WITH RECHARGEABLE BATTERY



The only entry level pallet truck scale with high-end features and quality made in Italy. Manufactured, calibrated and adjusted in Italy by Dini Argeo, using certified sample masses. Powered by internal rechargeable battery.

Working in cooperation with:

VETEK AB

HANTVERKSVÄGEN 15 - 76493 - VÄDDÖ - SWEDEN
Tel. +46176-208920, info@vetek.com, www.vetek.com

The best solution
for advanced industrial
applications

WEIGHING FEATURES

- Resolution: 0.2 kg.
- Maximum lifting capacity: 2000 kg.
- Precision: +/- 0.05% of maximum capacity (weighing of goods on Europallet with distributed load).

WHY CHOOSE TPWNB T DINI ARGEO

- The only entry level pallet truck scale that weighs with a resolution of 0.2 kg.
- It is the lightest on the market, while maintaining a robust and rigid carpentry to weigh accurately.
- The only one without junction box, with adjustment of each load cell from the display.
- 4 Dini Argeo approved steel load cells, with IP67 protection rate.
- The large 25 mm shockproof LCD display makes it easier to read.
- Backlighting with automatic switch-off, adjustable from the keyboard to adapt to any working conditions.
- Waterproof keyboard for industrial use.
- Power supply via internal rechargeable battery with 80h autonomy (battery charger with EU plug included in the supply).
- Programmable automatic switch-off, which extends the working autonomy.
- Each pallet truck is tested and supplied with the corresponding certificate to guarantee the declared accuracy.

THE EASIEST ONE TO RECALIBRATE AND REPAIR

- The only one without junction box: the adjustment of each individual cell is done comfortably from the keyboard.
- Spare and wear parts always available and ready for delivery.
- Service centres throughout Europe and the world.

MAIN FUNCTIONS

- Weighing functions: Zeroing, Tare, Preset Tare.
- Operating modes selectable directly by the user, via dedicated button:
 - lb/kg conversion
 - Free conversion factor (meter counter, litre counter, etc)
 - Weight totalisation
 - Piece counting
 - Hold.

AVAILABLE FOR IMMEDIATE DELIVERY

- Fast delivery with products always in stock.
- The protective packaging on pallets guarantees optimal protection of the product and is composed of entirely recyclable materials.

DETAIL 1



DETAIL 2



DETAIL 3




DETAIL 4



VERSIONS

Available versions

	Codice	Max (kg)	d (kg)	M (kg)
	<u>IPWNBT</u>	2000	0,2	--

Please take note that the column and the handle-bar require assembly.



www.diniargeo.com

“YOUR WORLDWIDE PARTNER FOR WEIGHING”

DINI ARGEO
FRANCE sarl
France

DINI ARGEO
GMBH
Germany

DINI ARGEO
UK Ltd
United Kingdom

DINI ARGEO WEIGHING
INSTRUMENTS Ltd
China

DINI ARGEO
OCEANIA
Australia



COMPANY HEADQUARTERS

Via Della Fisica, 20
41042 Spezzano di Fiorano - Modena - Italy
Tel. +39.0536 843418

VETEK AB

HANTVERKSVÄGEN 15 - 76493 - VÄDDÖ - SWEDEN

Tel. +46176-208920, info@vetek.com, www.vetek.com

SALES AND TECHNICAL ASSISTANCE SERVICE