

TPWE

TPWET "ENTERPRISE TOUCH SCREEN" SERIES PALLET TRUCK SCALE



Pallet truck fitted with digital weight indicator and advanced data management. Suitable for applications such as formulation, piece counting, totalisation, memorization of stock movements, bar code reading, printouts, etc. The wide range of available interfaces and software applications make this instrument truly be a mobile weighing station integrated to a company's computer system. Available also CE-M APPROVED.

Working in cooperation with:

Vetek AB

Hantverkarsvägen 15 - 76493 - Väddö - SWEDEN
Tel. 0046-176208920 Fax. 0046-176208929
patrik@vetek.com

**The best solution
for advanced industrial
applications**

MAIN FEATURES

- Maximum lifting capacity: 2000 kg.
- Accuracy: +/- 0.1% of the maximum capacity in the versions for internal use.
- Accuracy: +/- 0.05% of the maximum capacity in the "M" approved versions.
- Fork dimensions 1150 x 550 x 85 mm. Weighs about 125 kg.
- Bearing structure in extra thick sheet steel and oven-fire painted interior construction.
- Standard fitted with +/-160° swivelling column head.
- Steering wheels and double loading rollers with a poliurethane coating.
- 4 stainless steel IP68 shear-beam load cells.
- Weighing indicator with colour touch screen with easy to clean ABS waterproof IP65 enclosure built to withstand humid and dusty environments.
- Slot for built-in micro SD for recording logos.
- Configuration, calibration and diagnostics from keyboard or PC with DINITOOLS.
- Power supply through built-in extractable rechargeable battery. Fitted with battery charge.
- The operating time is of about 10 hours of continuous use, or 24/24h with second optional rechargeable battery.
- Programmable auto power saving function. Battery level indication.
- Equipped with 230Vac 50 Hz battery charger.
- RS232/C port for connection to printer, radio module, remote scale.
- RS232/C port on RJ connector for connection to PC.
- Fitted with time/date and Alibi Memory.
- Fitted with thermal printer with RS232/C dedicated bidirectional port (TPW20ETP and TPW20ETPM version).

AVAILABLE UPON PRICE ESTIMATE

- Special steering wheels.
- 680 mm fork width.
- Special fork length from 850 to 1500 mm.
- Special capacity e/o divisions.
- High resolution.

CUSTOMISED APPLICATIONS

Thanks to our integrated development, you can create complete customised applications in autonomy:

- wizards, operator messages
- serial port management, protocols customization
- digital I/O full management
- sequential or simultaneous automations
- data entry, custom archives

Dini Argeo can offer the service of custom development programs.

VERSIONS

Available versions

Codice	Max (kg)	d (kg)	M (kg)	d HR (kg)*
TPW20ETP	500 / 1000 / 2000	0,2 / 0,5 / 1	--	0,1 / 0,2 / 0,5
TPW20ETPM M	1000 / 2000	--	0,5 / 1	--

(*) The HR division is obtainable only with the relative EHR option



www.diniargeo.com



“YOUR WORLDWIDE PARTNER FOR WEIGHING,”

DINI ARGEO
FRANCE sarl
Nogent-sur-Marne

DINI ARGEO
GMBH
Sinsheim - Germany

DINI ARGEO
UK Ltd
Taunton - United Kingdom

DINI ARGEO WEIGHING
INSTRUMENTS Ltd
Shanghai - China

DINI ARGEO
WEIGHBRIDGES
Calto (RO) – Italy



HEAD OFFICE
Via Della Fisica, 20
41042 Spezzano di Fiorano Modena - Italy



Vetek AB

Hantverkstvägen 15 - 76493 - Väddö - SWEDEN

Tel. 0046-176208920 Fax. 0046-176208929

patrik@vetek.com

SALES AND TECHNICAL ASSISTANCE SERVICE