



HCH-WBF

HIGH CARE HYGIENIC
WEIGH BELT FEEDER



RICE LAKE[®]
WEIGHING SYSTEMS

www.ricelake.com

Datasheet_HCH-WBF_V1

HCH-WBF

HIGH CARE HYGIENIC WEIGH BELT FEEDER

Master HCH High Care Hygienic Weigh Belt Feeder

Rice Lake Weighing Systems' Master HCH high care hygienic weigh belt feeder is engineered to stand up to the intense cleaning necessary for food processing, chemical and pharmaceutical environments.

Built with continuous welds and stainless steel, the Master HCH is designed from top to bottom for applications that require highly sanitary conditions. The HCH is constructed without holes or creases, ensuring bacteria have no chance to invade your equipment and contaminate your product.

Ideal for wet environments, the HCH's stainless steel frame and IP69K load cells, stand up to powerful streams of water. The FDA-approved weigh belt features endless weldment to achieve a seamless flow of product while keeping harmful bacteria away from your product.

Foldable side boards and a flip up tail drum, create access to the complete conveyor internals, enabling a thorough washdown.

The self-tracking feature guarantees operation after cleaning, without any adjustments.

The HCH can be easily integrated into existing systems, offering complete control of flow regulation, to ensure the correct amount of product.

Legal for Trade and OIML approved options are also available.



HCH-WBF open for cleaning

- Foldable side boards and a flip up tail drum create access to the complete conveyor internals, enabling a thorough washdown
- Self-tracking feature guarantees operation after cleaning without any adjustments
- Easily integrated into existing systems, offering complete control of flow regulation to ensure the correct amount of product

Your Rice Lake Weighing Systems distributor is:

RICE LAKE
WEIGHING SYSTEMS

Rice Lake Weighing Systems Europe B.V.
Weiland 11 • NL-6666 MH Heteren • The Netherlands
TEL: +31 (0)26 472 1319 • FAX: +31 (0) 88 234 9100 • www.ricelake.com