

JBQAI

"JBQAI": EQUALISED JUNCTION BOX FOR ATEX ENVIRONMENTS



Stainless steel junction box with IP66 protection from water and dust, and fitted with an intrinsically safe electronic board for junction and equalisation of load cells. Terminal boards with screws for easing the connection of the load cells and signal adjustment trimmer, for an accurate and reliable equalisation.

Marking:

ATEX II 2G Ex ib IIC T6 Gb for gases.

ATEX II 2D Ex tb IIIC T115°C Db IP65 for dust.

The best solution
for advanced industrial
applications

TECHNICAL FEATURES

- Designed and made according to the ATEX 94/9/CE directive, group II category 2GD, according to the IEC/EN60079-0, IEC/EN60079-11, and IEC/EN60079-31 norms.
- Stainless steel case.
- Protection degree: IP66.
- Dimensions: 190x130x45mm (lxwxh).

NOTE: the dimensions are not compatibles for mounting on 4 load cells platforms/pallet weighers.

ATEX PARAMETERS OF THE JUNCTION BOX

- $U_o = U_i = 24V_{dc}$
- $I_o = I_i = 174mA$
- $C_o = C_i = 0mF$
- $L_o = L_i = 0mH$

or

- $U_o = U_i = 12V_{dc}$
- $I_o = I_i = 3,33A$
- $C_o = C_i = 0mF$
- $L_o = L_i = 0mH$



www.diniargeo.com



“YOUR WORLDWIDE PARTNER FOR WEIGHING,”

DINI AR GEO
FRANCE sarl
Nogent-sur-Marne
info.fr@diniargeo.com

DINI AR GEO
GMBH
Sinsheim - Germany
info.de@diniargeo.com

DINI AR GEO
UK Ltd
Taunton - United Kingdom
info.uk@diniargeo.com

DINI AR GEO WEIGHING
INSTRUMENTS Ltd
Shanghai - China
info.cn@diniargeo.com

DINI AR GEO
WEIGHBRIDGES
Calto (RO) - Italy
info@diniargeo.com



HEAD OFFICE

Via Della Fisica, 20
41042 Spezzano di Fiorano Modena - Italy
Tel. +39.0536 843418 Fax. +39.0536 843521
info@diniargeo.com

SERVICE ASSISTANCE

Via Dell'Elettronica, 15
41042 Spezzano di Fiorano Modena - Italy
Tel. +39.0536 921784 Fax. +39.0536 926654
service@diniargeo.com



SALES AND TECHNICAL ASSISTANCE SERVICE