



WEIGHING INDICATOR N320

FEATURES

- N320 is ideal for those applications, where a weight display is needed.
- Complete with Desk mount, Bracket, Batteries, Adapter.
- Outputs: Display 20 mm, RS232, 2 alarms, Opto link.
- Functions: Peak/hold, Hold, Counting, Backlight.
- OIML type approved.



The 20mm backlight LCD can be read under all conditions. Fast and safe cable connection by means of clamps.



The magnetically coupled opto-link on the front panel provides a convenient temporary connection to a laptop for:

- Transfer of setup and calibration of information
- Download of software upgrades

No need to access rear of the indicator.

OPTIONS

- Option M300-005 - PVC Transparent Cover for R300 Indicator.

Specially for very dirty environment like paint scales we have developed the protective cover for the R300 ABS-plastic instruments. The keys still can be operated. The display can be read clearly. Changing the cover is done in seconds.



- Option M300-ACC Recharge Pack for R300 Weight Indicator

The recharge pack M300-ACC enables to build mobile scales where the batteries are recharges in the instrument. Simply plug the connector and recharging starts. Scope of supply: Special battery housing with connector, high capacity NiMH rechargeable batteries and special power plug.

- Bracket

