



Universal digital force gauge (Push / Pull) with Peak-Hold function with RS-232

Features

- **Turnable display** with backlight
- **1** Can be mounted on all SAUTER test stands
- Digital force gauge with internal sensor
- **Data interface RS-232**, included
- **2** Standard attachments: as shown below, extension rod: 90 mm
- **3** Delivered in a hard carrying case
- Selectable measuring units: N, lb, kg
- **Real time or Peak Hold Mode** to observe transients or capture peaks
- **Function to set limits**, programming of Max./Min., in pull and push direction, with output of acoustic and optical signal. Ideal mode for efficient and accurate testing of standard parts
- **Auto-Power-Off**

- **Mini Statistics Kit**: calculates the average result from up to ten stored single results, min., max., n

Technical data

- High resolution: up to 10,000 points (total measuring range)
- Internal measuring frequency: 2000 Hz
- Precision: 0,5 % of [Max]
- Overload protection: 150 % of [Max]
- Dimensions LxWxH 230x66x35 mm
- Thread: M6
- Rechargeable battery pack internal, standard, operating time up to 12 h without backlight, charging time approx. 4 h
- Net weight approx. 0,64 kg


Accessories

- **Relais module**, serves to amplify the output signal of the dynamometer to control direct actions, SAUTER AFH-02
- **Force-time data transfer software** for graphical representation on the PC and data transfer to Microsoft Excel, SAUTER AFH FAST
- **Force-distance evaluation software** with graphic display of the measuring process, SAUTER AFH FD
- **Thermal printer**, SAUTER YKB-01N
- **Standard attachments**, SAUTER AC 43
- Further accessory see www.sauter.eu and page 21 et seq.

STANDARD

































OPTION



Model	Measuring range [Max] N	Readout [d] N	Option ISO Calibration Certificate			
			Tension		Compression	
			ISO KERN		ISO KERN	
SAUTER						
FH 2.	2	0,001	961-161		-	-
FH 5.	5	0,001	961-161		-	-
FH 10.	10	0,005	961-161		-	-
FH 20.	20	0,01	961-161		961-261	
FH 50.	50	0,01	961-161		961-261	
FH 100.	100	0,05	961-161		961-261	
FH 200.	200	0,1	961-161		961-261	
FH 500.	500	0,1	961-161		961-261	

Datasheet_FH-S_V1

	Adjusting program (CAL): For quick setting of the balance's accuracy. External adjusting weight required.		Data interface Infrared: To transfer data from the balance to a printer, PC or other peripheral devices.		Battery operation: Ready for battery operation. The battery type is specified for each device.
	Calibration block: standard for adjusting or correcting the measuring device.		Control outputs (optocoupler, digital I/O): to connect relays, signal lamps, valves, etc.		Rechargeable battery pack: rechargeable set.
	Peak hold function: capturing a peak value within a measuring process.		Analogue interface: to connect a suitable peripheral device for analogue processing of the measurements.		Mains adapter: 230V/50Hz in standard version for EU. On request GB, AUS or USA version available.
	Scan mode: continuous capture and display of measurements.		Statistics: using the saved values, the device calculates statistical data, such as average value, standard deviation etc.		Power supply: Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request.
	Push and Pull: the measuring device can capture tension and compression forces.		PC Software: to transfer the measurements from the device to a PC.		Motorised drive: The mechanical movement is carried out by a motorised drive.
	Length measurement: captures the geometric dimensions of a test object or the movement during a test process.		Printer: a printer can be connected to the device to print out the measurements.		Fast-Move: the total length of travel can be covered by a single lever movement.
	Focus function: increases the measuring accuracy of a device within a defined measuring range.		GLP/ISO record keeping: of measurements with date, time and serial number. Only with SAUTER printers.		ISO Calibration: The time required for ISO calibration is shown in days in the pictogram.
	Internal memory: to save measurements in the device memory.		Measuring units: Weighing units can be switched to e.g. non-metric at the touch of a key. Please refer to website for more details.		Package shipment: The time required for internal shipping preparations is shown in days in the pictogram.
	Data interface RS-232: bidirectional, for connection of printer and PC.		Measuring with tolerance range: Upper and lower limiting can be programmed individually, e.g. for sorting and dosing.		Pallet shipment: The time required for internal shipping preparations is shown in days in the pictogram.
	Data interface USB: To connect the balance to a printer, PC or other peripheral devices.		ZERO: Resets the display to "0".		Warranty: The warranty period is shown in the pictogram.

Your SAUTER specialist dealer: