



## TI-1200 GENERAL PURPOSE WEIGHING INDICATOR

TI-1200 is suitable for weighing applications as Personal Weighing Machines,Pallet Scales, Floor/deck Scales, Platform Scales, Mechanical conversion kits, etc.

TI-1200 is a general purpose, digital OEM indicator housed in a stainless steel NEMA enclosure. It comes with six 19 mm LCD digits with backlight. All parameters may be entered via the front panel keys.

The TI-1200 comes standard with a full duplex RS-232 serial port. Easy readout of up to 50.000 display divisions.

The Weighing Indicator does have 2 versions:

- TI-1200 is designed for battery applications with a rechargeable battery for many hours of operation.
- TI-1200-S does not have battery and the cabinet is smaller.

## **FEATURES**

- EC Type approved
- Auto power off function
- Standard interface RS232
- High precision
- Robust and compact in SS
- 6 digits LCD-Display
- Cost effective
- Option: Printer

## **SPECIFICATIONS**

Loadcell excitation:	5 VDC	
Max 350 ohms Loadcells:	4 pcs	
A/D int. conversion rate:	< 230.000	
Display	19 mm 7-segment, Liquid Crystal, 6-Digit, Back light	VITIKO
Key functions	Zero, Net/gross, Tare, Print, Ib/kg	
Serial port	RS232	
Operating temp.:	-10 to 40°C	TI-1200-S (utan batteri)
Power	AC Adapter 220 VAC / 9 VDC, 800 mA	
Rechargeable Battery	6 VDC, 3.0 Ah lead acid (only TI-1200)	
Vikt:	TI-1200 2,6 kg, TI-1200-S 1,2 kg.	
DimensionS:	TI-1200: 225 mm x 140 mm x 73 mm TI-1200-S: 200 mm x 116 mm x 40 mm	848
Approval	OIML class III CE	TI-1200 (med batteri)