

ELWL

ELWL "LOGISTIC" SERIES ELECTRIC PALLET TRUCK WEIGHING SCALE



Electric pallet truck scale, with built-in electronic weighing. Easy to use, reliable, suitable for harsh work conditions. It is indispensable when one needs to weigh accurately and save time. Available also CE-M approved.

Working in cooperation with:

Vetek AB

Hantverksvägen 15 - 76040 - Väddö - SWEDEN
Tel. 0046-176208920 Fax. 0046-176208929
olle@vetek.se

The best solution
for advanced industrial
applications

MAIN FEATURES (weighing)

- Maximum lifting capacity: 1200 kg.
- 4 shear-beam IP67 load cells and connections.
- Weight indicator with a 17-key, waterproof, numerical-functional keyboard; backlit 25mm LCD display with 6 high-contrast digits and with icons for showing the active functions.
- Easy to clean waterproof ABS IP65 case resistant to harsh and corrosive environments.
- Digital calibration and set-up configurable from keypad.
- Power supply through built-in rechargeable battery. Battery level indication.
- The operating time is of about 40 hours; programmable energy saving functions.
- Configurable RS232 / C bidirectional port for connection to the printer.
- Configurable RS232 / C bidirectional port for PC, modem radio or portable terminal.

ELECTRICAL AND MECHANICAL FEATURES

- Thick steel and oven-fire painted structure.
- Wheels with polyurethane coating.
- Distance from the centre of gravity: 600 mm.
- Fork height: 85 mm to max. 200 mm.
- Adjustable lowering speed.
- Maximum horizontal inclination: 10% at full load, 25% without load.
- Electromagnetic and parking brakes.
- 24 VDC 55 Ah battery and charger.
- Electric power supply 0.3 kw traction and in lifting 0,4 Kw.

MAIN FUNCTIONS

- Zeroing, Tare, Printing, numeric IDs
- High resolution display (x 10)
- Net / Gross or lb / kg conversion
- Accumulation
- Formulation
- + / - check weighing
- Percent weighing
- Counting (with max. resolution of 1,500,000 divisions)
- Hold and Peak

Options (only available at time of order)

- Thermal printer option box
- Radio modem option box
- WI-FI interface
- Alibi memory with time-date
- Date / Time

VERSIONS

Versioni disponibili

Codice	Max (kg)	d (kg)	M (kg)
ELWL12	600/1200	0,2/0,5	--
ELWL12M M	600/1200	--	0,5/1



www.diniargeo.com



“YOUR WORLDWIDE PARTNER FOR WEIGHING,”

DINI ARGEO
FRANCE sarl
Nogent-sur-Marne

DINI ARGEO
GMBH
Sinsheim - Germany

DINI ARGEO
UK Ltd
Taunton - United Kingdom

DINI ARGEO WEIGHING
INSTRUMENTS Ltd
Shanghai - China

DINI ARGEO
WEIGHBRIDGES
Calto (RO) – Italy



HEAD OFFICE
Via Della Fisica, 20
41042 Spezzano di Fiorano Modena - Italy



Vetek AB

Hantverksvägen 15 - 76040 - Väddö - SWEDEN

Tel. 0046-176208920 Fax. 0046-176208929

olle@vetek.se

SALES AND TECHNICAL ASSISTANCE SERVICE