

USBC

"USBC": USB PORT KIT WITH KEY FOR PC



USB port kit fitted with key for PC for over 5.000.000 storable weighs.

Working in cooperation with:

VETEK AB

HANTVERKSVÄGEN 15 - 76493 - VÄDDÖ - SWEDEN
Tel. +46176-208920, info@vetek.com, www.vetek.com

The best solution
for advanced industrial
applications

FEATURES

- Thanks to the USBC kit, you will be able to save all the weighs made during the work day, for a subsequent processing and saving on PC.
- The kit is made up of a built-in USB port inside the indicator and a fitted USB key. The USB port is installed in the rear of the indicator, replacing the standard RS232 port and occupying a serial port of the weight indicator.
- During the weighing operations, the key is protected by a special aluminum screw cap, which also guarantees an IP65 protection.
- The kit is compatible with all the indicators of the 3590E and DFW ranges, both with the ABS case as well as the stainless steel case.

FUNCTIONING

- The data can be saved when a key is pressed, and, when combined with a 3590E, these can be saved automatically in a certain amount of time, in order to monitor the weight decreases.

FORMAT OF THE SAVED DATA

- In combination with DFW indicators, it allows to store the same printed data, in the same format (in a .txt file).
- In combination with the 3590E indicators it is possible to completely customise the format and type of saved data, and optimize them for eventual compatibility with databases and programs, or for the simple processing with Excel.

DETAIL 1



USBC with protective cap

DETAIL 2



USBC: key for storage the weights.



www.diniargeo.com



“YOUR WORLDWIDE PARTNER FOR WEIGHING,”

DINI AR GEO
FRANCE sarl
Nogent-sur-Marne

DINI AR GEO
GMBH
Sinsheim - Germany

DINI AR GEO
UK Ltd
Taunton - United Kingdom

DINI AR GEO WEIGHING
INSTRUMENTS Ltd
Shanghai - China

DINI AR GEO
WEIGHBRIDGES
Calto (RO) – Italy



HEAD OFFICE
Via Della Fisica, 20
41042 Spezzano di Fiorano Modena - Italy



VETEK AB

HANTVERKSVÄGEN 15 - 76493 - VÄDDÖ - SWEDEN

Tel. +46176-208920, info@vetek.com, www.vetek.com

SALES AND TECHNICAL ASSISTANCE SERVICE