

3590ETKR

3590ETKR "TOUCH": Touch Screen weight indicator with transport case



Digital weight indicator with a big touch screen display, suitable for the weighing of vehicles, planes and objects with multiple points of support. It allows the visualization of all the weighing data and the customization of the screens, simplifying the user operations. Fitted with 3 serial ports, transmission protocols for data communication, completely configurable printouts, integrated alibi memory, and port for connection to barcode/badge reader. CE-M approvable (OIML R-76 / EN 45501).

Vetek AB

Hantverkarsvägen 15, 76493 Vaddö - Sweden

Tel. +46176-208920, info@vetek.com, www.vetek.com

**The best solution
for advanced industrial
applications**

MAIN FEATURES

- ABS transport case, with housing for the indicator and space for extra accessories.
- 3590ET series indicator fit in a metallic rack type involucre with dimensions of 270x440mm, complete of housing for printer, connectors for platforms, and serial output on 9-pole connector.
- **Backlit graphic display with touch screen technology**, lxh= 120x90mm size. **Screens completely customizable.**
- **Multilanguage software.**
- QWERTY, AZERTY o QWERTZ keyboard integrated in the touch screen, selectable.
- Dimensions: 325x460x170 mm. Weight: about 5kg.
- Fitted with attached thermal printer.
- Real time clock and permanent data storage.
- Fitted alibi memory, integrated on the motherboard.
- Slot for built-in micro SD for recording the configuration, logos, and customized screens (upon request).
- **Functions available with DINITOOLS utility**
 - Configuration, data entry and print formatting.
 - Recording and filing of all the information on PC.
 - Complete retrieval of the configuration.
 - Instrument calibration with numeric values.
 - Customization of the screens.
- 24-bit A/D converter, 4 channels, up to 3200 conv./sec. and up to 8 signal linearisation points.
- 4 independent analogue channels (up to 2 in the E-AF03 version) for reading of the weight.
- Connection with up to 16 analogue load cells of 350 Ohm (45 load cells of 1000 Ohm) and with the main digital load cells available on the market (mod. E-AF03).
- Up to 10.000e OIML or 3 x 3000e @ 0,3 μ V/d CE-M legal for trade.
- Up to 1.000.000 displayable divisions for internal factory use, with internal resolution up to 3.000.000 points.
- Connectable to printers and labellers with free programming of the printout formats.
- Power supply through built-in rechargeable battery, the operating time is of about 10 hours.

CUSTOMISED APPLICATIONS

Thanks to our integrated development, you can create complete customised applications in autonomy:

- wizards, operator messages
- serial port management, protocols customization
- digital I/O full management
- sequential or simultaneous automations
- data entry, custom archives

Vetek can offer the service of custom development programs.

I/O SECTION

- **Available on panel:**

- One RS232 serial ports, for connection to PC, on 9-pole connector.

- **Available on internal side:**

- 1 RS232 serial ports, for connection to printer, radio module, PC or PLC, badge reader or remote scale.
- 1 RS232 serial port (**optional RS485**), for connection to printer, remote scale, badge reader, or digital load cells.
- Fitted keyboard emulation input, for barcode/badge readers or external PC keyboard, through cable with mini DIN connector (optional).
- Up to 4 optoisolated outputs (**optional**).
- Up to 2 optoisolated inputs (**optional**).

DETAIL 1

~		GROSS		5740		S		
PT U1		kg		10:39		06/11/14		
2	1350	4	1495	PARTIAL		0		
2810		2930		WHEELS		0		
1		1460	3	1435	VEHICLE		AW 1543 M	
TARE		1500		GRAVITY CENTRE		x= 1.51 y= 0.75		
kg								
LOAD THE SCALE								
ZERO		M+		TOTAL		>>		

3590ETKR - 4 platform display example (AF08 software)