

3590EGT3GD

3590EGT "GRAPHIC TOUCH" 3GD: TOUCH SCREEN INDICATOR FOR ATEX 2 & 22 ZONES



Weight indicator with a big touch screen display, suitable for advanced industrial applications in ATEX areas classified at risk of explosion with protection methods according to ATEX II 3G Ex nR IIC T6 Gc X ATEX II 3D Ex tc IIIC T135°C Dc IP68 X. Fitted with programmable inputs and outputs, 3 serial ports, completely configurable printouts, and integrated alibi memory. CE-M approvable (OIML R-76 / EN 45501).

Working in cooperation with:

Vetek AB

Hantverksvägen 15 - 76493 - Väddö Tel. +46176-208920, info@vetek.com, www.vetek.com The best solution for advanced industrial applications

MAIN FEATURES

- Backlit graphic display with touch screen technology, lxh= 120x90mm size.
- Multilanguage software.
- 15-key alphanumerical waterproof keyboard.
- 3-way control light.
- QWERTY keyboard integrated in the touch screen.
- Stainless steel waterproof IP68 enclosure, with new IP68 protection system.
- Dimensions: 280x143x185 mm.
- Suitable for use on the table, column, or wall.
- Real time clock and permanent data storage.
- Fitted alibi memory, integrated on the motherboard.
- Slot for built-in micro SD for recording the configuration, logos, and customized screens (upon request).
- Functions available with DINITOOLS utility
 - Configuration, data entry and print formatting.
 - Recording and filing of all the information on PC.
 - Complete retrieval of the configuration.
 - Instrument calibration with numeric values.
 - Customization of the screens.
- 24-bit A/D converter, 4 channels, up to 3200 conv./sec. and up to 8 signal linearisation points.
- 4 independent analogue channels for reading of the weight.
- Connection with up to 16 analogue load cells of 350 Ohm (45 load cells of 1000 Ohm).
- Up to 10.000e OIML or 3 x 3000e @ 0,3 μ V/d CE-M legal for trade.
- Up to 1.000.000 displayable divisions for internal factory use, with internal resolution up to 3.000.000 points.
- Connectable to printers and labellers with free programmation of the printout formats.
- 110-240 Vac power supply.

MAIN CERTIFICATIONS

- EC Type Approval (EN45501)
- OIML R76
- OIML R51 MID
- OIML R134 (AF09)

I/O SECTION

- Two RS232 serial ports, for connection to printer, radio module, PC or PLC, badge reader or remote scale.
- One RS232/RS485 serial port, for connection to printer, PC, PLC, or digital load cells.
- 4 optoisolated outputs.
- 2 optoisolated inputs.
- Profibus interface to install in safety zone.

Description 1										ı
										ı
Esc		`	<	/	1	Clear		BkSp		ı
1	2	3	4	5	6	7	8	9	9	ı
q	3	е	r	t	y	u	i	0	р	l
а	5	d	f	g	h	j	k	1	;	
2̂F	z	×	С	٥	b	n	n	,		
Shift		+					→	ок		
3590EGT ZOINI ARGE										
							•		and state	_



QWERTY keyboard integrated into the Touch Screen display.

3590EGT3GD: view of the back fitted with PC serial port protected by cap, fairlead for platform and 5 holes at disposal.





DINI ARGEO FRANCE sarl Nogent-sur-Marne DINI ARGEO **GMBH**

Sinsheim - Germany

DINI ARGEO UK Ltd

Taunton - United Kingdom

DINI ARGEO WEIGHING INSTRUMENTS Ltd

Shanghai - China

DINI ARGEO WEIGHBRIDGES Calto (RO) - Italy



HEAD OFFICE Via Della Fisica, 20 41042 Spezzano di Fiorano Modena - Italy







Vetek AB

Hantverksvägen 15 - 76493 - Väddö $Tel.\ +46176\text{-}208920,\ in fo@vetek.com,\ www.vetek.com$

SALES AND TECHNICAL ASSISTANCE SERVICE